

Wacom User Help

DTH172



[About the Wacom Cintiq Pro 17](#)
[Set up your device](#)
[Work with your pen](#)
[Customize your Wacom device](#)
[Wacom Center](#)
[Open Wacom Tablet Properties](#)
[On-screen shortcuts](#)
[Application-specific settings](#)
[Touch & gestures](#)
[Built-in display settings](#)
[Using the Wacom Color Manager](#)
[Wacom Support](#)
[Glossary](#)
[Order parts and accessories](#)
[Care for your device](#)
[About this document](#)



wacom®

Table of Contents

Table of Contents	2
About the Wacom Cintiq Pro 17	5
Topics on this page	5
Included with your Wacom Cintiq Pro 17	5
Find more information	6
Features of your Wacom Cintiq Pro 17	7
Topics on this page	7
Illustrated Guide	7
Feature descriptions	7
Set up your device	9
Stand setup and usage	10
Connect to your computer	11
Connect your Wacom Cintiq Pro 17 to your computer	11
Install the Wacom driver	13
Install the Wacom driver	13
Update the Wacom driver from Wacom Center	13
Work with your pen	14
Customize your Pro Pen 3	15
Topics on this page	15
Add a pen grip and weight	15
Remove the pen grip and weight	15
Use your pen	17
Pen tip	17
Pen eraser	17
Pen buttons	17
Store your pen	18
Where to store your pen	18
Customize your pen settings	19
Assign actions to the pen button and pen tip	19
Replace the pen nib	20
Topics on this page	20
Replace the pen nib	20
Where to find the nib remover	20
Where to find replacement nibs	21
Use your pen with Windows Ink	22
Advanced pen and eraser	23
Customize advanced pen and eraser settings	23
Customize your Wacom device	25
Assign an action	25
Example: Set a pen button to zoom in	25
What actions can I assign?	26
Assign keystrokes	29
ExpressKeys	30
Pop-up notifications	31
Turn Pop-up notifications off or on	31
Settings view	32
Assign and use Settings view	32
Display toggle	33
Topics on this page	33
Set up Display toggle	33
Example: Using Display toggle	34
Actions that return the toggle sequence back to your pen display	34
Pen tip to cursor alignment	35
Advanced settings for your device	36
Wacom Center	37
Topics on this page	37
The Wacom Center main screen	37
Get to know Wacom Center	37
Navigation bar	38
Devices sidebar	38

Main content area	39
Quick help bar	39
Action sidebar	40
Open Wacom Center	41
Access and customize your device	42
Topics on this page	42
Access information about your device	42
Customize your device settings	42
Viewing the device's serial number	42
Run the setup wizard	42
Store and retrieve your settings	44
Topics on this page	44
Back up your settings	44
Restore your settings	44
Reset all settings for all devices	44
Register your device and redeem software	45
Topics on this page	45
Sign in, sign up, or edit your Wacom ID	45
Register your Wacom device	45
Redeem software offers	45
Keep everything up to date	46
Updating your device	46
Solve common problems and get help	47
Topics on this page	47
Check the driver	47
Run diagnostics	47
Turn on driver logging	47
Access Wacom Support	47
Open Wacom Tablet Properties	48
On-screen shortcuts	49
Setup and use Grid panels and Radial menus	49
Use Pen gestures	49
Create On-screen shortcuts	50
Create a Grid panel or Radial menu	50
Customize On-screen shortcuts	51
Assign On-screen shortcuts	53
Topics on this page	53
Assign a Radial menu or Grid panel to a pen button	53
Assign a Pen gesture to a pen button	53
Edit On-screen shortcuts	54
Topics on this page	54
Copy a Radial menu or Grid panel	54
Rename a Radial menu or Grid panel	54
Edit a Radial menu or Grid panel	54
Delete a Radial menu or Grid panel	54
Change a Grid panel layout	54
On-screen shortcut layouts	55
Topics on this page	55
Grid panel layouts	55
Radial menu layout	55
Pen gesture layouts	56
Application-specific settings	57
Topics on this page	57
Create an Application-specific setting	57
Remove an Application-specific setting	57
Remove all Application-specific settings from a pen	57
Touch & gestures	59
Touch setup	60
Basic gestures	61
Customize Basic gestures	61
Advanced gestures	62
Create custom touch gestures	62

Advanced gestures recognition	62
Built-in display settings	63
Customize the built-in display settings	63
Using the Wacom Color Manager	64
Wacom Support	65
Test the creative pen display	66
Test the pen	67
Test the ExpressKeys	68
Test touch	69
Glossary	70
Order parts and accessories	72
Care for your device	73
About this document	74
Topics on this page	74
Things to know about User Help	74
Device features listed in User Help	74
Access User Help	74
Trademarks	75
Privacy	76
Wacom Experience Program for Tablet Driver	76



About the Wacom Cintiq Pro 17

Your Wacom Cintiq Pro 17 creative pen display helps you express yourself by allowing you to create directly on your screen.

- Use the customizable [Pro Pen 3](#), which is included with your Cintiq Pro, or another supported pen.
- Interact with your device using [Touch & gestures](#) to perform functions using multi-finger swipes and taps.
- Improve your work flow with the Cintiq Pro's eight [ExpressKeys](#), to quickly execute frequently used actions such as mouse clicks, keyboard shortcuts, and more.
- Use the [Cintiq Pro 17 Easy Stand](#) included with your Cintiq Pro 17.
- Check out other accessories that can help you work with the Cintiq Pro, such as the angle-adjustable Cintiq Pro 17 Stand or the Wacom Color Manager. Both are available from the [Wacom eStore](#).

See [Features of your Wacom Cintiq Pro 17](#) for illustrations and information about your creative pen display. See [Set up your device](#) for setup instructions, including how to [Connect to your computer](#).













Topics on this page

- [Included with your Wacom Cintiq Pro 17](#)
- [Find more information](#)


Included with your Wacom Cintiq Pro 17

After you unpack your Cintiq Pro 17, make sure the following items are included:

Cintiq Pro 17 creative pen display	
Power adapter with cable tie attached	
Power cord	
USB-C to C cable	
Quick Start Guide booklet	
Pro Pen 3	

	
Pen grips	 1X  1X
Weight	
Button plates	
Pen nibs	 5X  5X
Pen nib removal tool	
Pro Pen 3 Tray	
Easy Stand  1X	
Screws & hex wrench	 4X  1X

Find more information

- Access FAQs and other product information on the [Cintiq Pro Getting Started](#) page of the Wacom website.
- Review the Important Product Information, which describes safety precautions, specifications, warranties, and the license agreement for your device, available in the Help & support  section of [Wacom Center](#).

| Do not share my information | [Cookies](#) | [Terms of use](#) | [Privacy Policy](#) | [California Privacy](#)

Features of your Wacom Cintiq Pro 17


Topics on this page

- [Illustrated guide](#)
- [Feature descriptions](#)


Illustrated Guide




	Kensington Security Slot
	Status LED



	Mini DisplayPort
	USB-C DisplayPort™ Alt Mode (supports graphics input)
	HDMI
	USB-C for power connection














	Power button
	Built-in display settings button
	On/Off slider for touch input
	Accessory attachment
VESA 75 x 75	VESA 75mm x 75mm mounting holes
ExpressKey	Eight ergonomically located, recessed hand-grip ExpressKeys (pictured in both images)



Feature descriptions

Illustration	Feature	Description
	Kensington Security Slot	This slot can be used to attach a locking cable to secure your pen display to a specific location, like your desk.
		The light indicates the power state of your Cintiq Pro and whether a pen is in contact with it. The light is:

	Status LED	<ul style="list-style-type: none"> • Blue when powered on with no pen in use. • Orange when the pen display is in standby. • White when a compatible pen is in contact with the display. • Off when the pen display is off.
	Mini DisplayPort	Use this port if your computer does not have a USB-C port that supports video output, but does have DisplayPort.
	USB-C supports graphics input	Use this port to connect to your computer using any of the connection methods outlined on the Connect to your computer page. This USB-C port supports graphics input.
	HDMI port	Use this port if your computer does not have a USB-C port that supports video output, but does have an HDMI port.
	USB-C power port	Use this USB-C port to connect the power adapter to the Cintiq Pro.
	Power button	Press the power button to turn the device on and off.
	Built-in display settings button	<p>You can use the Cintiq Pro's built-in display controls to adjust a variety of display settings.</p> <div style="background-color: #e0f2f7; padding: 5px; border: 1px solid #ccc;"> <p> Important: The Cintiq Pro's display settings are optimized out of the box. Customizing these built-in display settings is an advanced feature.</p> </div>
	Touch input slider	Use the slider to quickly enable or disable the touch feature.
	Accessory attachment	Can be used for third-party attachments. (Not for use with the Pro Pen 3 tray or Extension table.)
VESA 75 x 75		Use the VESA mounting holes to attach the Easy Stand (included in the box), the Cintiq Pro 17 stand (available in the Wacom eStore), or a third-party stand or arm that complies with the VESA 75mm x 75mm standard.
ExpressKey		Use the eight customizable ExpressKeys to activate time-saving actions .

 **Tip:** See [Connect to your computer](#) for detailed information on how to connect the Cintiq Pro to your computer.

| Do not share my information | [Cookies](#) | [Terms of use](#) | [Privacy Policy](#) | [California Privacy](#)

Set up your device

The topics that contain the specific instructions needed to help you set up your device are within this **Set up your device** section in the Table of Contents.

If you cannot already see the setup topics, click  next to **Set up your device** in the Table of Contents on the left.

The Quick Start Guide included in the product box contains images that can also help guide you through the setup process.

| [Do not share my information](#) | [Cookies](#) | [Terms of use](#) | [Privacy Policy](#) | [California Privacy](#)

Stand setup and usage

To attach the Easy Stand included with your Cintiq Pro 17, use the instructions below. To attach another VESA-compliant stand, use the VESA mounting holes on the back of your Cintiq Pro.




Important: The Wacom Cintiq Pro 17 is designed to be used with the included Easy Stand (instructions below), the Wacom Cintiq Pro 17 Stand (available on the [Wacom eStore](#)), or a third-party stand or arm that complies with the VESA 75mm x 75mm standard.



Warning: Using this product without a stand may damage the ExpressKeys and cause injury due to instability during use. Please be sure to use this product with a stand as instructed.


1. Place the Cintiq Pro screen-side down onto a soft cloth.




2. Attach the Easy Stand to the VESA mounting holes using the 4 screws and the hex wrench included with your Cintiq Pro.



Important: Attach the wider stand piece (highlighted in blue) to the bottom of the Cintiq Pro.



3. Turn the Cintiq Pro upright.







[Do not share my information] [Cookies](#) | [Terms of use](#) | [Privacy Policy](#) | [California Privacy](#)


Connect to your computer

After you have removed your Cintiq Pro from the box and are ready to begin using it, complete the steps below to connect to your computer. You can also reference the Quick Start Guide included in the Cintiq Pro box.


Connect your Wacom Cintiq Pro 17 to your computer

1. Connect your Cintiq Pro to your computer using one of the methods illustrated in the table below, depending on your computer's setup:


Port(s) on your computer	Cable(s) needed to connect the Cintiq Pro to your computer
USB-C DisplayPort™ Alt mode (supports video output)	USB-C to C cable 
USB-C port (does not support video output) DisplayPort	USB-C to C cable DisplayPort cable (available on the Wacom eStore) 
USB-C port (does not support video output) HDMI port	USB-C to C cable HDMI cable (available on the Wacom eStore) 
USB-A port DisplayPort	USB-C to A cable DisplayPort cable (both cables available on the Wacom eStore) 
USB-A port HDMI port	USB-C to A cable HDMI cable (both cables available on the Wacom eStore)




2. Connect your device to a power source using the power cable and AC adapter. The power connection port is on the back, right side of your Cintiq Pro.



3. Wrap the cables together using the cable tie attached to the Power adapter.



4. Press the power switch to turn your Cintiq Pro on.



5. Follow the instructions on the [Install the Wacom driver](#) page.

Install the Wacom driver



Important: Download and install the latest Wacom driver so your device is fully functional.

Install the Wacom driver


1. Go to the "Resources for your Wacom device" page: www.wacom.com/download.
2. In the search bar, enter your product's name or model number.
3. Select your product from the resulting drop-down list.
4. Scroll down and click **Download Windows Driver** or **Download Mac Driver**, depending on your computer's operating system.
5. Save the driver file to an easy-to-find folder on your computer.
6. Double click on the downloaded file to run it.
7. Follow the Installation Wizard steps.
8. Restart your computer.



Important: For **macOS**, installing the driver requires enabling Privacy & Security settings. Please see the instructions for [setting up the Wacom driver for macOS](#).

Update the Wacom driver from Wacom Center


Updated Wacom drivers are periodically made available on both the "Resources for your Wacom device" page (see instructions above) and in [Wacom Center](#) (see instructions below). Check in and update regularly so your device has the latest features and functionality.

1. [Open Wacom Center](#).
2. Click the Global settings  icon to proceed to the **General settings** tab.
3. If a "Driver update" is listed in the **Software updates** section, click the **Install update** button.
4. Follow the on-screen instructions.

| Do not share my information | [Cookies](#) | [Terms of use](#) | [Privacy Policy](#) | [California Privacy](#)

Work with your pen

Wacom devices include a cordless, battery-free pen that you use to interact with your device. You can hold, write, and draw as you normally would with a pen or pencil.



Pen styles vary depending on the Wacom device that you purchased.

To discover other pens and tools that can be used with your Wacom device, go to the [Wacom Store](#).

| [Do not share my information](#) | [Cookies](#) | [Terms of use](#) | [Privacy Policy](#) | [California Privacy](#)

Customize your Pro Pen 3

The Pro Pen 3 comes with button plates (thick and thin), pen grips (flared and straight), a pen weight, and a variety of extra pen nibs. These parts allow you to fully customize the pen's look and feel.


Note: Pen parts may or may not be preinstalled, depending on your Wacom device model.

Topics on this page


- [Add a pen grip and weight](#)
- [Remove the pen grip and weight](#)

Add a pen grip and weight

1. Remove the button plate using your fingernail or a suitable, non-metallic tool and then remove the rear case.




2. Slide one of the pen grips onto the pen.




3. Attach a thick button plate by sliding the small lip on the end of the plate into the section nearest the pen tip. Then push the plate down into place.

Note: A **thick** button plate is required when installing a pen grip.



4. Insert the heavy (A) or light (B) end of the weight toward the pen tip.



5. Reinstall the rear case.

Remove the pen grip and weight


1. Remove the rear case.



2. Remove the weight.



3. Remove the button plate using your fingernail or a suitable, non-metallic tool.




4. Slide the pen grip off of the pen.



5. Attach the same or a new button plate by sliding the small lip on the end of the plate into the section nearest the pen tip. Then push the plate down into place.



Note: A **thin** button plate is required if you have removed the pen grip.



6. Reinstall the rear case.

| [Do not share my information](#) | [Cookies](#) | [Terms of use](#) | [Privacy Policy](#) | [California Privacy](#)

Use your pen

Use your pen to interact with your device. This includes drawing, writing, moving items, and activating actions that you assign to pen buttons.

Hold the pen as you would normally hold a pen or pencil. Adjust your grip so that you can press any pen buttons easily with your thumb (recommended) or index finger. Make grip adjustments to avoid accidentally pressing the pen buttons.

Pen tip

- **Draw or sign:** Draw or sign with the pen tip directly on the device surface.



Note: Pens are pressure-sensitive, so the harder you press, the thicker your lines and the denser the color.

- **Move the cursor:** Move the pen while holding it slightly above the device without touching the surface.
- **Double-click:** Quickly tap the device surface twice in the same place with the pen tip.
- **Select an item:** Tap the device surface once with the pen tip.
- **Move an item:** Select the item with the pen tip, then slide the pen tip across the device surface to move it.

Pen eraser

For pens that have erasers, flip the pen to the side opposite the pen tip and move the eraser over the area you want to erase, just as you would use the eraser on a pencil.



Note: Not all pens have erasers.

Pen buttons

Use pen buttons to trigger [actions](#). Customize your pen button settings in Wacom Center by selecting your device in the [Devices sidebar](#), then selecting your Pen.

If your pen button is assigned to a type of click (right-click, double-click, etc.), you activate the click based on your **Pen button mode**. Pen button mode settings can be found the pen's advanced settings in Wacom Center.

Pen button mode	How to activate the click
Hover click	Hold the pen tip slightly above the surface of your device and press the pen button.
Click & tap	Press the pen button and then tap the device surface with your pen tip.



Note: If your pen has a long, thin button, press the upper part of the button for one setting and the lower part for another.

| [Do not share my information](#) | [Cookies](#) | [Terms of use](#) | [Privacy Policy](#) | [California Privacy](#)





Store your pen

Store your pen properly to keep it in good condition and help the pen tip last longer.

! **Important:** Store your pen so there is no pressure on the pen tip or eraser.



Where to store your pen

If your device included a pen stand, you can store the pen with the tip down in the stand.	 <p>Pen stand examples</p>
If your device has a pen holder or tray, the pen can be stored there.	 <p>Pen holder examples</p>
	 <p>Pen tray example</p>
If your device included a pen case, store the pen in the case.	 <p>Pen case example</p>

💡 Tip: Do not leave the pen on the device when you are not using the pen. This might cause issues when you are using a mouse and might prevent your computer from going to sleep.

| Do not share my information | [Cookies](#) | [Terms of use](#) | [Privacy Policy](#) | [California Privacy](#)

Customize your pen settings

Customize your pen by assigning actions to pen buttons, adjusting the pen tip feel and pressure, and selecting how you perform a right-click.



Note: Some pens do not have buttons or an eraser.

Assign actions to the pen button and pen tip

1. Open [Wacom Center](#).
2. Select the device you use your pen with from the [Devices sidebar](#).
3. Select your pen in the Devices sidebar.
4. Select a pen button, then make a selection from the [Action sidebar](#).
5. To see how hard you need to press with the pen, check your current pressure by pressing down with the pen tip or eraser in the **Test area**.




Tip: Use the **Tip sensitivity** slider to change the amount of pressure you need to use the pen tip. For pens that have erasers, use the **Eraser sensitivity** to change the amount of pressure.

6. Optionally customize [advanced pen and eraser](#) settings such as: Double tap distance, Pressure, Pen button mode, Tip-up assist, and Windows Ink, depending on your device.



Warning: The pen tip must be set to **Click** in order to draw for most graphics applications.



Hover your mouse over features in the interface to learn helpful information.
The above screenshot is for descriptive purposes; it may not match your screen.

| [Do not share my information](#) | [Cookies](#) | [Terms of use](#) | [Privacy Policy](#) | [California Privacy](#)

Replace the pen nib




Tip: Replace your pen nib when it is approximately 1 mm (1/25 inch) or has a sharp edge.

Topics on this page


- [Replace the pen nib](#)
- [Where to find the nib remover](#)
- [Where to find replacement nibs](#)

Replace the pen nib

1. If it is included with your device, use the round, metal nib removal tool to remove your pen nib. If the metal nib removal tool is not included, use a built-in nib remover. Also see: [Where to find the nib remover](#).



Round, metal nib removal tool



A built-in nib remover, located in a variety of locations.

2. Get a [replacement nib](#) and slide the end of the new nib straight into the barrel of the pen.



3. Push the nib in slowly and firmly until it stops.


Where to find the nib remover

Many devices come with a round, metal **nib removal tool** included in the box with your Wacom device:




Other devices come with a **built-in nib remover**, which can be located in a variety of locations:


On the bottom of a pen stand:




On the removable pen holder attached to the side of your device:




Underneath one of the built-in stand legs:



Inside the pen:



Inside the pen holder:



Where to find replacement nibs

The extra nibs are stored in different places for different devices. First, look in the box that your device was packaged in. If you do not see the nibs there, try these places:

- If your pen can be disassembled, nibs can be stored inside the pen.
- If your device included a pen case, check there.
- If your device has a removable compartment cover on the back, slide it open.
- If your device included a pen stand, unscrew the pen stand.



Tip for the Pro Pen 2 stand: To screw the stand back together, line up the dots on the bottom of the stand and the recess. Then, gently guide the bottom of the stand to the right until you feel it click into place.

- If your device includes a pen holder attachment, check there.
- If your device has built-in stand legs, the replacement nibs may be located underneath one of the legs.

If you need more nibs, you can purchase them from the [Wacom Store](#).

| Do not share my information | [Cookies](#) | [Terms of use](#) | [Privacy Policy](#) | [California Privacy](#)

Use your pen with Windows Ink

Take advantage of a wide variety of features supported by Microsoft Windows. Additional features are supported by Windows 10 & 11 and the Windows Ink Workspace.

- **Handwriting recognition:** Convert your handwritten content to typed text.
- **Digital Ink:** Use the enhanced digital mark-up and inking tools found on the Review tab in applicable applications.
- **Windows Input Panel:** Use handwriting or an on-screen keyboard to directly enter text with your Wacom pen.



Note: The Pen Flicks and press-and-hold-to-right-click features are disabled in some graphics applications.

Windows Ink is ON by default. To turn Windows Ink OFF:

1. [Open Wacom Center](#).
2. Select your device in the [Devices sidebar](#).
3. Select your pen.
4. In the [main content area](#), click **Advanced**.
5. Turn **Windows Ink** off.

| Do not share my information | [Cookies](#) | [Terms of use](#) | [Privacy Policy](#) | [California Privacy](#)

Advanced pen and eraser


You can further customize pen tip or eraser pressure settings in Advanced settings. Options within the Advance settings let you independently change the tip or eraser pressure sensitivity, click threshold settings, your Pen button mode, and more.





Customize advanced pen and eraser settings

1. Open [Wacom Center](#).
2. Select the device you use your pen with in the [Devices sidebar](#), then select your pen.


 **Tip:** If your pen does not display in Wacom Center, tap your pen to your device.

3. In the [main content area](#), click **Advanced**.
4. In the Advanced settings area, make the changes to your pen and/or eraser settings. Descriptions for each customizable setting are listed in the table below.

 **Important:** The available Advanced settings will vary, depending on your device.

<p>Double-tap distance</p>	<p>The maximum distance (in screen pixels) that the screen cursor can move between clicks and still be accepted as a double-click. Increasing the double-click distance makes double-clicking easier, but may cause a delay in brush strokes in some graphics applications.</p> <p> Tip: If you notice a delay at the beginning of brush strokes, inking strokes, or drag actions, reduce the Double-tap distance or set a pen button to double-click instead of the pen tip.</p>
<p>Tip sensitivity and Eraser sensitivity</p>	<p>The selected pressure sensitivity curve and click threshold settings are displayed. A curve that increases quickly makes the pen feel more sensitive. Move the pressure controls to change the settings:</p> <ul style="list-style-type: none"> • Max pressure: Determines how hard you must press the pen tip to reach maximum pressure. • Sensitivity: Changes the slope of the pressure response curve. • Click threshold: Determines the amount of force required to register pressure or generate a pen click. <p>Using your pen tip or eraser, make several strokes within the Test area section to test the results of your changes.</p> <p> Tip: If the pen overreacts to slight pressure, try a firmer Tip sensitivity setting.</p> <p> Tip: If you want a narrower range of pressure values in a pressure-sensitive application, select a soft Tip sensitivity.</p> <p> Note: Pressure and sensitivity settings are adjusted with the Tip Sensitivity and Eraser Sensitivity sliders in the main content area of Wacom Center. Any adjustments you make there will override changes made to the Tip Sensitivity and Eraser Sensitivity settings in Advanced settings.</p>
<p>Pen button mode</p>	<p>Select how you want to double-click or perform another click function with your pen:</p> <ul style="list-style-type: none"> • Hover click: This is the default Pen button mode setting. Hold the pen tip close to your device and press the pen button to perform a right-click or other click action (double-click, etc.). • Click & tap: If your Pen button mode is Click & Tap, press down the pen button and then touch the device surface with your pen tip to perform a right-click or other click action (double-click, etc.). This option allows for a more precise placement of pen clicks.
<p>Tip-up assist</p>	<p>This feature is turned on by default and helps you accurately place a crosshair or control point with your pen in the exact place that you are targeting, without moving the targeted location 1-2 pixels when you release pressure on the pen tip. To turn off Tip-up Assist, deselect the checkbox.</p>
<p>Windows</p>	<p>This feature is turned on by default and allows you to take advantage of a wide variety of features supported by Microsoft Windows. Additional features are supported by Windows 10 and the Windows Ink Workspace:</p> <ul style="list-style-type: none"> • Handwriting recognition: Convert your handwritten content to typed text.

<p>Ink</p>	<ul style="list-style-type: none"> • Digital Ink: Use the enhanced digital mark-up and inking tools found on the Review tab in applicable applications. • Windows Input Panel: Use handwriting or an on-screen keyboard to directly enter text with your Wacom pen.
<p>Pen tip to cursor alignment</p>	<p>If you are using a Wacom pen display, by default, your cursor will display directly under the pen tip. This feature allows you to display the cursor slightly away from your pen tip.</p>



© Hover your mouse over features in the interface to learn helpful information.
 The above screenshot is for descriptive purposes; it may not match your screen.

[Do not share my information] [Cookies](#) | [Terms of use](#) | [Privacy Policy](#) | [California Privacy](#)

Customize your Wacom device

You can set a customizable component of your device to perform a specific action. Customizable components can include ExpressKeys, pen buttons, the pen tip, and Touch & gestures. Actions can include mouse clicks, keyboard shortcuts (Ctrl+Z, etc.), navigation (scroll up or down, etc.), Display toggle, and more.



Note: The customizable components and actions available may vary, depending on your device.

Assign an action

1. [Open Wacom Center](#).
2. Select your device in the [Devices sidebar](#).



Note: Any customizations apply to this device only, except for On-screen shortcuts, which apply to all devices.

3. Select a customizable component (pen, ExpressKeys, etc.).
4. In the [main content area](#), click the currently assigned action next to the component you want to customize. The [Action sidebar](#) will open.
5. Select the [action](#) you want to assign.
6. Engage the component that you customized and the action that you assigned is performed.

Example: Set a pen button to zoom in

The following example describes how to customize a pen button to **Zoom in**. Use these instructions as a guide to help you create your own customizations.

1. [Open Wacom Center](#).
2. Select your device in the [Devices sidebar](#).
3. Select your pen.
4. In the [main content area](#), click the currently assigned action next to the pen button you want to customize.
5. In the [Action sidebar](#), select **Zoom in** under "Navigation".
6. Press the pen button and your application zooms in.



Tip: You can create settings for your pen, ExpressKeys, etc. that apply only in a specific application. See [Application-specific settings](#) for more information.

[Do not share my information] | [Cookies](#) | [Terms of use](#) | [Privacy Policy](#) | [California Privacy](#)





What actions can I assign?





You can change the [actions](#) assigned to pen buttons, ExpressKeys, On-screen shortcuts, Touch & gestures, Touch rings, and other [customizable components](#) from [Wacom Center](#). Then, when you use that component, such as pressing a pen button or ExpressKey, the action you assigned is performed.



Note: The customizable components available on your device may vary from those listed above. The actions available for each customizable component will also vary.

Action name	Action performed
4th click or 5th click	Performs a 4th or 5th mouse button click (only applies if your mouse has more than 3 buttons).
Arrow keys	Only applies to Pen gestures. Allows you to move incrementally up, down, left, or right by moving the pen tip while pressing a pen button or ExpressKey. The exact behavior depends on the active application.
Auto Scroll/Zoom	Assign this action to the Touch Ring to zoom in most graphics applications or scroll in most other applications.
Back	Returns you to the previous step, similar to how Back works in browsers.
Change settings	Opens Wacom Center or Wacom Tablet Properties (depending on which you use to customize your device) so you can make settings changes.
Click	Performs a mouse button click.
Click lock	<p>Presses and holds the mouse button.</p> <ul style="list-style-type: none"> Begin the click lock by engaging a customizable component, and then engage it again to release it. For example, if Click Lock is assigned to a pen button, press the pen button once to begin Click Lock and press it again to release the lock. <div style="background-color: #fff9c4; padding: 5px; margin-top: 10px;"> Tip: Click Lock is helpful when you are dragging objects or selecting blocks of text. </div>
Default	Resets the customizable component to its default setting.
Disabled	Disables the customizable component so that when you engage the component, such as pressing the pen button, nothing happens.
Display toggle	Switches between your devices and monitors, if you are using your device with multiple monitors or devices.
Double click	<p>Performs a double-click.</p> <div style="background-color: #fff9c4; padding: 5px; margin-top: 10px;"> Tip: For easier double-clicking, assign this action to a customizable component, such as a pen button, instead of tapping twice with the pen tip. </div>
Erase	<p>Sets your strokes with the pen to erase instead of draw.</p> <p>For example, if you assign Erase to your pen button, you can move your pen over an area you want to erase while pressing the pen button.</p>
Forward	Directs you to a step ahead of where you are in your history, similar to how Forward works in browsers.
Grid panels	Displays the Grid panel that you select.
Keyboard modifier	A Keyboard modifier (Shift, Alt, etc.) or mouse button click (left click, etc.) that you can assign to a customizable component on the Keyboard modifier window.
Keyboard shortcut	A combination of keystrokes (Ctrl+Z, Ctrl+Y) that you can assign to a customizable component on the Keyboard shortcut window.
Launchpad	Displays the macOS Launchpad menu, where you can start applications.
Middle click	Performs a middle mouse button click.
	<p>Assign this action to a pen button to toggle between Pen mode and Mouse mode.</p> <ul style="list-style-type: none"> When you first set a pen button to Mode Toggle, the Mouse Mode window appears. Move the sliders to adjust the mouse acceleration and speed.

<p>Mode toggle</p>	<ul style="list-style-type: none"> In Pen mode, you use the pen like a regular pen. The cursor jumps to the point where you place your pen, and you define which portion of your device maps to which portion of your monitors. In Mouse mode, you use the pen like a mouse. The cursor stays on the point you left it when you pick up your pen, and you interact with your device like you interact with a mousepad.
<p>Modifier</p>	<p>Performs a keyboard modifier (Shift, Alt, etc.), mouse button click (left click, etc.), mouse wheel scroll, or a combination of these options that you select on the Define Modifier window.</p>
<p>On-screen keyboard</p>	<p>Toggles the Windows On-Screen Keyboard open and closed.</p>
<p>Open/Run</p>	<p>Opens or runs the application, file, or a script you choose.</p> <ul style="list-style-type: none"> When you select Open/Run, the Run Application window appears. Click Browse and select the item. Click OK.
<p>Pan/Scroll</p>	<p>Allows you to pan or scroll by moving the pen tip up and down or right and left while pressing a pen button or ExpressKey. Your screen cursor will remain in place while you move the pen tip.</p> <div style="background-color: #fff9c4; padding: 5px;">  <p>Tip: You can change the Speed, which determines how much you need to move the pen to pan or scroll. Slower settings require moving the pen longer distances, while faster settings require moving the pen shorter distances.</p> </div>
<p>Pan/Scroll (Legacy)</p>	<p>Behaves the same as Pan/Scroll, but your screen cursor will move with the pen tip.</p> <div style="background-color: #fff9c4; padding: 5px;">  <p>Tip: You can change the Speed, which determines how much you need to move the pen to pan or scroll. Slower settings require moving the pen longer distances, while faster settings require moving the pen shorter distances.</p> </div>
<p>Pan/Zoom</p>	<p>Pans or zooms, depending on whether you are hovering or touching the device surface.</p> <ul style="list-style-type: none"> To pan, hover above (but do not touch) the device surface, and then press and hold the pen button or ExpressKey while moving your pen. To zoom, press and hold the pen button or ExpressKey while touching the device surface and move the pen towards the top to zoom out or towards the bottom to zoom in. <ul style="list-style-type: none"> If you pick up your pen to hover, zooming stops. As long as you continue to hover and hold the button, you can still zoom when you touch the pen tip to the surface again. If you want to pan again after zooming, release the button and press it again. <div style="background-color: #e8f5e9; padding: 5px;">  <p>Note: If the application does not support Pan/Zoom, the following happens instead:</p> <ul style="list-style-type: none"> Pressing the pen button or ExpressKey while hovering activates a Ctrl + Right-Click. Pressing the pen button or ExpressKey while touching the surface activates a mouse wheel scroll. </div> <div style="background-color: #fff9c4; padding: 5px;">  <p>Tip: You can change the Speed, which determines how much you need to move the pen to pan or zoom. Slower settings require moving the pen longer distances, while faster settings require moving the pen shorter distances.</p> </div>
<p>Precision mode</p>	<p>Precision mode toggles between normal precision and a precision that you choose - from Fine to Ultra fine.</p> <p>The following descriptions assume that "Precision mode" is assigned to a pen button:</p> <ul style="list-style-type: none"> Press and release the pen button to work with the selected precision around the location where Precision mode is initiated. Press and release the pen button again to switch back to normal precision. Press and hold the pen button to switch to Precision mode around the initiation location. Pull the pen out of the tablet's proximity and then reenter proximity to relocate the Precision mode window to the newer pen tip location.
<p>Pressure</p>	<p>Locks the pressure at the current level until you release the customizable component.</p> <p>For example, if you assign this action to a pen button, you can paint with pressure sensitivity</p>

hold	enabled in your application until you reach the brush size you like. Then, press and hold the pen button to lock in that brush size as long as you are pressing and holding the button.
Radial menus	Displays the Radial menu that you select.
Redo	Restores any actions that were previously undone using an undo.
Right click	Performs a right mouse button click.
Scroll	<p>Scrolls the active application on your computer.</p> <p>Assigned to a Touch Ring: Slide your finger around the ring clockwise to scroll down and counterclockwise to scroll up.</p> <p>Assigned to a pen button or ExpressKey: Press and hold the pen button or ExpressKey while touching the pen tip to the device surface and moving up or down to scroll. If you pick up your pen to hover, scrolling stops. As long as you continue to hover and hold the button, you can still scroll when you touch the pen tip to the surface again.</p> <div style="background-color: #fff9c4; padding: 5px; border: 1px solid #ccc;"> <p> Tip: You can change the Speed to determine how much you need to move the pen to scroll. Slower settings require moving the pen longer distances, while faster settings require moving the pen shorter distances.</p> </div>
Scroll down	Scrolls your active application down.
Scroll up	Scrolls your active application up.
Settings	Displays the current settings of your customizable components, including ExpressKeys, the Touch Ring, pen, and touch. Click on an item to adjust its settings.
Show desktop	Minimizes all open windows so you can view your desktop.
Switch application	Switches between the applications that you have open.
Touch On/Off	Turns touch on and off. This setting is not available on devices that have a built-in touch on/off switch.
Tumble	<p>Tumbles, orbits, or rotates items in 3D applications.</p> <div style="background-color: #e8f5e9; padding: 5px; border: 1px solid #ccc;"> <p> Note: If the application does not support Tumble, pressing the button activates a middle-click instead.</p> </div>
Undo	Reverses your last action.
Zoom	<p>Zooms the active application on your computer.</p> <p>Assigned to a Touch Ring: Slide your finger around the ring clockwise to zoom in and counterclockwise to zoom out.</p> <p>Assigned to a pen button or ExpressKey: Press and hold the pen button or ExpressKey while touching the pen tip to the device surface and move toward the top to zoom out or toward the bottom to zoom in. If you pick up your pen to hover, zooming stops. As long as you continue to hover and hold the button, you can still zoom when you touch the pen tip to the surface again.</p> <div style="background-color: #e8f5e9; padding: 5px; border: 1px solid #ccc;"> <p> Note: If the application does not support Zoom, pressing the pen button or ExpressKey activates a mouse wheel scroll instead.</p> </div> <div style="background-color: #fff9c4; padding: 5px; border: 1px solid #ccc;"> <p> Tip: You can change the Speed to determine how much you need to move the pen to zoom. Slower settings require moving the pen longer distances, while faster settings require moving the pen shorter distances.</p> </div>
Zoom in	Zooms your active application in.
Zoom out	Zooms your active application out.

[Do not share my information] [Cookies](#) | [Terms of use](#) | [Privacy Policy](#) | [California Privacy](#)

Assign keystrokes

You can assign keystrokes to customizable components of your device. As a result, pressing a pen button, ExpressKey, etc. performs the specified function instead of pressing the keystroke on your keyboard. You can also assign a combination of keystrokes, so you only have to press one button instead of an entire keystroke combination.

1. Open [Wacom Center](#).
2. In the [Devices sidebar](#), select your device, then select one of your device's customizable components (ExpressKeys, for example).
3. In the [main content area](#), select the button you wish to customize.
4. From the [Action sidebar](#), select **Keyboard** then select **Keystroke...** to open the Keyboard shortcut window.

Keyboard shortcut

Use your pointing device to move between the boxes and click OK to accept or Cancel to exit.

Keys

Add special keys
 Select key

Name

The above screenshot is for descriptive purposes; it may not match your screen.

5. Enter a keystroke combination in the **Keys** box (Ctrl+Z, for example).
 - o You can enter letters, numbers, function keys (F2, F3, etc.), and modifier keys (Ctrl, Alt) in combination with other keys. Use the **Add special keys** drop-down list to select additional keystroke options.
 - o Click the **Delete** button to remove the last keystroke you entered. Click the **Clear** button to remove all the keystrokes.
6. Enter a **Name** for your keystroke and click **Apply**.
 - o The name appears on On-screen shortcuts and in Settings view, so enter a name that indicates the keystroke you assigned.
 - o If you are assigning numbers to a Keypad, it is best practice to name the Keystroke the number that you assigned. For example, if you assign the number 8 to a Keypad button, name the Keystroke **8**.



Note: If no **Name** is entered, the keystroke keys will display: {Ctrl}z, for example.



Tip: You can assign different keystroke combinations to the same customizable component for different applications. See [Application-specific settings](#) for more information.



Tip: To learn which keystroke combinations are built-in as shortcuts for a particular application, refer to the documentation for the application.

[Do not share my information] [Cookies](#) | [Terms of use](#) | [Privacy Policy](#) | [California Privacy](#)

ExpressKeys


ExpressKeys are customizable buttons on your Cintiq Pro. When you press an ExpressKey, you activate the assigned action, such as a mouse click, a modifier key (Shift, Ctrl, etc.), keystrokes and keystroke combinations (Ctrl+Z, etc.), navigation functions (scroll up, show desktop, etc.), and [more](#).

The ExpressKeys on your Cintiq Pro are located on the left and right back sides of your device.

Your Cintiq Pro ExpressKeys come with the same key assignments on both the left and right sides. But you can change the assignments to create eight unique ExpressKey settings.

You can view and change which actions are assigned:

1. [Open Wacom Center](#).
2. Select your Cintiq Pro in the [Devices sidebar](#), then select **ExpressKeys**.
3. In the [main content area](#), click the currently assigned action for the ExpressKey that you wish to customize.
4. Select the new action you wish to assign from the [Action sidebar](#).



ⓘ Hover your mouse over features in the interface to learn helpful information.
The above screenshot is for descriptive purposes; it may not match your screen.



Tip: ExpressKey settings can be defined for use with specific applications. See [Application-specific settings](#) for more information.

| Do not share my information | [Cookies](#) | [Terms of use](#) | [Privacy Policy](#) | [California Privacy](#)

Pop-up notifications

Pop-up notifications allow you to see your ExpressKey settings and the Touch On/Off pop-up notification, which displays when you log into Windows or macOS.

Pop-up notifications also control the **Display toggle pop-up** icon, which shows you which display your pen is mapped to when using the Display toggle feature.

Turn Pop-up notifications off or on

1. [Open Wacom Center](#).
2. Select your device in the [Devices sidebar](#).
3. In the [main content area](#), click **Advanced**.
4. On the Advanced settings screen, turn the **Pop-up notifications** slider to On or Off.



Note: Pop-up notifications may vary in appearance, depending on your device model.


| [Do not share my information](#) | [Cookies](#) | [Terms of use](#) | [Privacy Policy](#) | [California Privacy](#)

Settings view

You can view the current settings for the pen button(s), ExpressKeys, Rocker ring, Touch ring, Touch Strips, and Touch on/off at any time by activating Settings view.



Note: Your Settings view display may vary, depending on your pen display model.



The above screenshot is for descriptive purposes; it may not match your screen.

Assign and use Settings view

These steps describe how to assign Settings view to an pen button. You can also assign Settings view to an ExpressKey, On-screen shortcut, Advanced touch gesture, or another customizable component, depending on your device features.

1. [Open Wacom Center](#).
2. Select your device in the [Devices sidebar](#).
3. Select your pen.
4. In the [main content area](#), click the currently assigned action next to a pen button.
5. In the [Action sidebar](#), click **Other**, then select **Settings** to assign Settings view to the pen button.
6. To view the settings on the screen, press the pen button.



Note: Any customizable component that has been disabled will display as "Disabled" in Settings view.



7. To close Settings view, click on it with your mouse, tap it with your pen, or press the button a second time.

| Do not share my information | [Cookies](#) | [Terms of use](#) | [Privacy Policy](#) | [California Privacy](#)

Display toggle

The Display toggle feature allows you to work with your Wacom device on all connected display screens, or on one display screen at a time. In Display toggle settings, you can select and deselect the display(s) to include – or exclude – in the toggle sequence.

After you select the displays that you wish to include in the Display toggle sequence, you assign "Display toggle" to a customizable component, such as a pen button. Then you can use that customizable component to toggle the pen mapping from one display to another.


 **Tip:** The Express view setting controls the **Display toggle pop-up**  icon, which shows you which display your pen is mapped to when using the Display toggle feature.

Topics on this page


- [Set up Display toggle](#)
- [Example: Using Display toggle](#)
- [Actions that return the toggle sequence back to a pen display](#)

Set up Display toggle



1. Open [Wacom Center](#).
2. Select your device in the [Devices sidebar](#).
3. Select **Display toggle**.


 **Important:** Display toggle is only active when your device is connected to a multi-screen setup and the computer's display properties are extended (not duplicated).

4. Select or deselect the box next to a display screen to include or exclude it in the toggle cycle.
5. Assign "Display toggle" to one of your device's customizable components, such as a pen button, ExpressKey, or On-screen shortcut. See [Customize your Wacom device](#) for detailed instructions.

 **Note:** Assigning "Display toggle" to a customizable component is required to toggle the pen mapping from one display to another.

6. Use the customizable component you assigned to "Display toggle" in the previous step to toggle between your display screens.
7. Optionally select the following feature(s), depending on whether your Wacom device is a Pen display or a Pen tablet:


Pen displays	
Feature	Description
Force Proportions	Adjusts the size of the active area to maintain correct vertical and horizontal proportions between your pen display and the entire desktop or display. Depending on your settings, some portions of the pen display may not accept pen input during Display toggle. When deselected, the correct scale or proportions are not maintained.
Use Inset Area	<p>Inset Area reduces the input area on your Wacom pen display so you can use shorter, more efficient pen strokes to navigate across the full width and length of your connected display(s).</p>  <p style="text-align: center; font-size: small;">Inset Area illustration on the Display toggle settings page in Wacom Center.</p> <p> Tip: To show the Inset Area illustration (image above), use Display toggle to toggle away from your Wacom pen display.</p>

 **Note:** If both **Force proportions** and **Use Inset Area** are selected, the active area sizing may be more limited.

Pen tablets	
Mapping	Press the Mapping setup button to change the mapping for your device.

Example: Using Display toggle

The following example describes the Display toggle setup in the image below. The example assumes that the user is currently working on the Wacom One pen display and that "Display toggle" is assigned to a pen button.



If the user presses the pen button assigned to "Display toggle", the pen cursor will move from the Wacom One (1) to the full display setup (2).

The next press of the pen button will move the pen cursor to the last display (4), skipping screen 3 because it has been excluded from the Display toggle sequence (A).

One more press of the pen button will bring the pen cursor back to the Wacom One pen display (1). The cycle then repeats until a new Display toggle sequence is created.

The above screenshot is for descriptive purposes; it may not match your screen.

Tip: The arrows along the sides of the Display toggle setup screen illustrate the cursor's movement between screens.

Actions that return the toggle sequence back to your pen display

Any of the actions listed below will return the toggle sequence to your pen display.

Note: These actions do not apply to pen tablets.

- Logging out of or rebooting the system.
- Switching users.
- Placing the system in sleep mode.
- Changing the resolution or number of displays on your system.
- Using the Mode Toggle... action.
- Selecting Pen Mode or Mouse Mode from On-screen shortcuts.

| Do not share my information | [Cookies](#) | [Terms of use](#) | [Privacy Policy](#) | [California Privacy](#)

Pen tip to cursor alignment

The pen-tip-to-cursor alignment feature allows you to change where the cursor displays in relation to the pen tip. By default, the cursor displays directly under your pen tip. Use the steps below if you want the cursor to display slightly away from your pen tip.



Tip: Changing the pen-tip-to-cursor alignment might be useful if your viewing angle prevents you from seeing the cursor when working with your pen on the pen display.

1. Open [Wacom Center](#).
2. Select your pen display in the [Devices sidebar](#).
3. If you are working with **multiple displays**: click **Advanced** in the [main content area](#) and confirm that the same pen display you selected above is also selected in the **Assigned display** drop-down.
4. In the Devices sidebar, select your **pen**, then click **Advanced** to open advanced **pen settings**.
5. Click **Pen tip to cursor alignment**.



Note: The crosshair represents your pen tip. The blue dot represents where your cursor appears on the pen display.

6. Move the blue dot away from the crosshair to change where your cursor appears on your pen display in relation to your pen tip. You can move the blue dot by:
 - Using the up and down arrows to set the **Horizontal offset** and **Vertical offset**.
 - Dragging the blue dot away from the crosshair with your pen tip or mouse.
7. Click **Apply**.
8. With your pen display in its working position, test the newly configured alignment by using the pen in a few different areas on the pen display. Make any additional adjustments as needed.







Tip: Click **Reset** to set the cursor-to-pen-tip alignment back to the default setting.

| Do not share my information | [Cookies](#) | [Terms of use](#) | [Privacy Policy](#) | [California Privacy](#)

Advanced settings for your device

You can further customize various preferences for your device on the Advanced settings screen.

1. [Open Wacom Center](#).
2. Select your device in the [Devices sidebar](#).
3. In the [main content area](#), click **Advanced**.
4. Edit your Advanced settings. See the table below for setting descriptions.

 Important: The available options listed below will vary, depending on your device.	
Pop-up notifications	<p>This feature is turned on by default and enables the display of:</p> <ul style="list-style-type: none"> ◦ A pop-up window that shows your ExpressKey settings (and your Dial/Touch ring settings, depending on your device features) when you press an ExpressKey. ◦ The Display toggle pop-up icon, which shows you which display your pen is mapped to when using the Display toggle feature. ◦ The Touch On/Off pop-up, which displays when you log into Windows or macOS. <div style="background-color: #fff9c4; padding: 5px; margin-top: 10px;">  Tip: To disable all pop-up windows, turn Pop-up notifications off. </div>
Wireless timeout	<p>This feature is turned on by default and automatically shuts down a wirelessly connected device after 15 minutes to preserve the battery charge and life. Turn this feature off to disable the auto-shutdown.</p> <div style="background-color: #e8f5e9; padding: 5px; margin-top: 10px;">  Note: Not all devices have a Wireless timeout. </div>
Disable all ExpressKeys	<p>Click this button to disable all ExpressKeys, Dials, and Touch rings (depending on your device features) for all currently connected devices.</p>
Assigned display	<p>If you are working with multiple displays, select the display corresponding to your Wacom device from the drop-down menu to assure that your pen is mapping to your Wacom device.</p>
Run Setup wizard	<p>The Setup wizard will run automatically when you first connect your device to Wacom Center. Click this button to view helpful features about the selected device, as well as register your device.</p> <div style="background-color: #e8f5e9; padding: 5px; margin-top: 10px;">  Note: Not all devices have a Setup Wizard. </div>
Diagnostics	<p>Click Diagnostics to display dynamic information about your Wacom device, tool(s), and information for touch-sensitive devices. Use the information shown in the dialog to test your device and tools.</p>

[Do not share my information](#) | [Cookies](#) | [Terms of use](#) | [Privacy Policy](#) | [California Privacy](#)

Wacom Center

Wacom Center provides you with an easy, intuitive way to access your Wacom device and settings. [Open Wacom Center](#) to:

- Customize the settings for your pen, ExpressKeys, Touch & gestures, and more.
- Create On-screen shortcuts (formerly On-Screen Controls).
- Update the Wacom driver and device firmware.
- Access User Help, Wacom Support, and Important Product Information.
- Create and edit your Wacom ID, register your device, and redeem software offers (does not apply to Enterprise devices).



Note: The appearance of Wacom Center can vary, depending on the attached device(s) and configuration.

Topics on this page

- [The Wacom Center main screen](#)
- [Get to know Wacom Center](#)

The Wacom Center main screen

For devices that you can customize directly in Wacom Center, your main screen will look similar to the image below.



Hover your mouse over features in the interface to learn helpful information. The above screenshot is for descriptive purposes; it may not match your screen.

For devices that you can customize in Wacom Tablet Properties, Wacom Center provides settings links (Pen settings, ExpressKey settings, etc.) for easy access to Wacom Tablet Properties. The Wacom Center main screen for these devices will look similar to the image below.



Hover your mouse over features in the interface to learn helpful information. The above screenshot is for descriptive purposes; it may not match your screen.

Get to know Wacom Center

To learn about the features available in the various sections of Wacom Center, click on one of the following links, or on a highlighted section of the screen shot below.

- [Navigation bar](#) (green highlight)
- [Devices sidebar](#) (blue highlight)
- [Main content area](#) (yellow highlight)
- [Quick help bar](#) (purple highlight)
- [Action sidebar](#) (not pictured)



The above screenshot is for illustrative purposes; it may not match your screen.

Navigation bar

The navigation bar is located at the top of Wacom Center and contains the features described in the table below.



The above screenshot is for illustrative purposes; it may not match your screen.

Forward & Back buttons	The Forward → and Back ← buttons move you forward one page or return you to the previous page within Wacom Center.
Devices	Select Devices in the navigation bar to display a list of your connected devices in the Devices sidebar .
On-screen shortcuts	Select On-screen shortcuts in the navigation bar to create and/or edit Radial menus, Grid panels, and – on some devices – Pen gestures.
Software offers	Log in with your Wacom ID and register your device to view, download, and redeem any available software offers (does not apply to Enterprise devices).
Profile settings	Click the Profile icon to create (or log into) your Wacom ID and register your device. Registering your device gives you access to any available software offers and other Wacom promotions (does not apply to Enterprise devices).
Global settings	Click the Global settings icon to access the following tabs: <ul style="list-style-type: none"> • General settings: Update your Wacom driver and device firmware, turn on/off the Quick help bar, set whether Wacom Center automatically starts when you turn on your computer, or run troubleshooting options. • Devices manager: This tab displays all of your connected devices and pens. From this tab you can register any device that is not currently registered. Click the Edit link to give your device or pen a custom name, or reset all of your settings to the factory defaults. • Backup & restore: Create backup files and restore your device settings.
Help & support	Click the Help & support icon to access links to User Help, tutorials, Important Product Information, customer support, and Wacom's social media sites. You can also perform a Wacom driver check, report a bug, and find your Wacom Center version number. <div style="background-color: #e0ffe0; padding: 5px; margin-top: 10px;"> <p>Note: Some Help & Support features do not apply to Enterprise devices.</p> </div>

Devices sidebar

The Devices sidebar is located on the left side of Wacom Center and lists each device that is currently connected to your computer. To add a new device to this list, connect the device to your computer.

For some devices, you can click the drop-down arrow next to the device name in the Devices sidebar to open the

device's customizable components (Pen, ExpressKeys, Touch & gestures, etc.). Click on a component to customize it in the **main content area**.



The above screenshot is for illustrative purposes; it may not match your screen.

For other devices, when you select your device in the Devices sidebar, settings links (Pen settings, ExpressKey settings, etc.) will display in the **main content area**. Click on a settings link to open it for customizing in Wacom Tablet Properties.

Main content area

The main content area is located in the center of Wacom Center and is where you can either customize your device settings (A) or access your device settings (B).


- A. Customize your device in the main content area when you select a customizable component (Pen, ExpressKeys, etc.) in the **Devices sidebar**. The component and the Application-specific settings feature will open in the main content area, where you can make all your customizations:



The above screenshot is for illustrative purposes; it may not match your screen.

Tip: Video tutorials that may display at the bottom of the main content area can help you learn more about your Wacom device.

- B. Access your device's settings links (Pen settings, ExpressKey settings, etc.) and Help resources in the main content area when you select a device name in the **Devices sidebar**. Click a settings link to open Wacom Tablet Properties, where you can make all your customizations.



The above screenshot is for illustrative purposes; it may not match your screen.

Quick help bar

The Quick help bar  is located at the bottom of Wacom Center. When you hover over a feature, text displays in the Quick help bar describing that feature.



The above screenshot is for illustrative purposes; it may not match your screen.



Note: On macOS, the Quick help bar content will display as a Tooltip next to the feature you hover over.

Action sidebar

The Action sidebar opens when you click on a customizable component (On-screen shortcut key, pen button, ExpressKey, etc.). The Action sidebar is organized so that Recommended actions are displayed at the top. The Recommended actions change based on your product and the feature you are customizing.

Click a drop-down arrow next to a category name (Clicks, Keyboard, etc.) to open the actions available within that category. Select an action from the list to assign it to a customizable feature. Press the **Esc** key or click in a blank area of Wacom Center to close the Action sidebar.



The above screenshot is for illustrative purposes; it may not match your screen.

| [Do not share my information](#) | [Cookies](#) | [Terms of use](#) | [Privacy Policy](#) | [California Privacy](#)

Open Wacom Center

In [Wacom Center](#), you can access your device and tool settings (Pen, ExpressKeys, etc.). How you open Wacom Center depends on your computer operating system.

- **Windows:** From your applications list, select **Wacom Tablet > Wacom Center**.
- **macOS:** From the Applications folder, open the **Wacom Tablet** folder then double-click the **Wacom Center** icon. Or, open Wacom Center from **Launchpad**.

| [Do not share my information](#) | [Cookies](#) | [Terms of use](#) | [Privacy Policy](#) | [California Privacy](#)


Access and customize your device

Selecting **Devices** in Wacom Center's [navigation bar](#) will display the supported Wacom device(s) connected to your computer in the [Devices sidebar](#). Selecting a device name in the Devices sidebar allows you to access helpful information about your device. It is also the first step in the process of customizing your device.

Topics on this page

- [Access information about your device](#)
- [Customize your device settings](#)
- [View your device's serial number](#)
- [Run the setup wizard](#)

Access information about your device

1. [Open Wacom Center](#).
2. Select your device in the [Devices sidebar](#).
3. Click the Help & support  icon in the [navigation bar](#) to access:



Note: Some of the Help & support options are not available on Enterprise devices.

- **User Help:** Opens the online User Help for your device.
- **Tutorials:** Opens Wacom's YouTube channel in your browser. Provides access to getting started videos and other helpful videos on a variety of features.
- **Important Product Information*:** Online product information for your device, including Product Specifications as well as License and Warranties.
- **Support or Contact:** Opens Wacom's Customer support page.
- **Send feedback:** Allows you to send feedback to Wacom about this application, including bug reports.
- **Driver check:** Click this button if you notice unusual behavior with your device and want to check for any driver errors.
- **About:** Click this button to view the driver version you are currently using. You can also link to Wacom's Tablet Driver Privacy Notice.
- **Social media links:** (differ by region) Wacom's social media or blog sites.

Customize your device settings

1. [Open Wacom Center](#).
2. Click the down arrow next to your device in the [Devices sidebar](#) to open its settings (Pen, ExpressKeys, etc.).
3. Click on a setting name to open it in the [main content area](#).
4. The settings you can modify in the main content area can include:



Note: The features available to customize will depend on your device.

- **Pen:** Customize how your pen operates, including pen button click behavior, and tip feel (depending on your pen).
- **ExpressKeys:** If your Wacom device has ExpressKeys, you can customize the button functions.
- **Touch & gestures:** If your Wacom device has touch, you can customize touch gestures and other touch functionality.
- **Display toggle:** Customize how your cursor moves between your Wacom device and multiple screens.
- **Display settings:** Customize color and other settings for your pen display.



Important: Your Wacom device's display settings are optimized out of the box. Customizing display settings is an advanced feature.

5. Click the currently assigned action next to any customizable component (pen button, ExpressKey, etc.), then select the [action that you want to assign](#) from the [Action sidebar](#).

Viewing the device's serial number

1. [Open Wacom Center](#).
2. Select your device in the [Devices sidebar](#).
3. Click **Advanced** in the [main content area](#).
4. Click the **Diagnostics** button.
5. Your device's serial number will be listed in the **Tablet S/N** field.

Run the setup wizard

The Setup Wizard runs automatically when you first install your device. You can run it at any time from Wacom Center to view helpful features about the selected device, as well as register your device.



Note: Not all devices have a Setup Wizard.

1. [Open Wacom Center](#).
2. Select your device in the [Devices sidebar](#).
3. Click **Advanced** in the [main content area](#).
4. Click the **Run setup wizard** button (if available) and follow the prompts.

| [Do not share my information](#) | [Cookies](#) | [Terms of use](#) | [Privacy Policy](#) | [California Privacy](#)

Store and retrieve your settings

The **Backup & restore** tab in Wacom Center allows you to backup and restore your device settings. You can also reset all device settings to their factory defaults.

Topics on this page

- [Back up your settings](#)
- [Restore your settings](#)
- [Reset all settings for all devices](#)

Back up your settings

1. [Open Wacom Center](#)
2. Click the Global settings  icon.
3. Select the **Backup & restore** tab.
4. Click the **New backup** button to proceed to the New backup window.
5. Enter a **Name** for your backup, then click the **Save** button.




Tip: To edit the backup file name, click the pen icon. To delete a backup file, click the trash icon.

Restore your settings

A list of your saved backup files displays on the **Backup & restore** screen. The backup files are sorted by their creation date.




Tip: If you don't see your backup file in the list, click the **Import backup** button to find it.

1. [Open Wacom Center](#)
2. Click the Global settings  icon.
3. Select the **Backup & restore** tab.
4. In the Actions column, click **Restore** next to the backup file you wish to restore.
5. The settings from the backup file will be applied to all devices.

Reset all settings for all devices



Important: When you reset all settings, **all** devices will have their settings returned to the factory defaults (whether the devices are currently connected to your computer or not).

1. [Open Wacom Center](#)
2. Click the Global settings  icon.
3. On the General settings tab, click the **Reset all settings** button.
4. All settings for all devices will be returned to their factory defaults.

[Do not share my information] [Cookies](#) | [Terms of use](#) | [Privacy Policy](#) | [California Privacy](#)

Register your device and redeem software

Use the steps below to create a new – or sign into an existing – Wacom ID account. With your Wacom ID account you can register your device, as well as gain access to software offers.




Note: The registration and software redemption features do not apply to Enterprise devices.


Topics on this page

- [Sign in, sign up for, or edit your Wacom ID](#)
- [Register your Wacom device](#)
- [Redeem software offers](#)

Sign in, sign up, or edit your Wacom ID

1. [Open Wacom Center](#).
2. Click the Profile  icon.
3. If you already have a Wacom ID, sign into your account. If you do not have a Wacom ID, click the **Sign up** link and create your profile.
4. To edit your Wacom ID profile, sign into your account and select **Edit Profile**.

Register your Wacom device

1. [Open Wacom Center](#).
2. Click the Global settings  icon.
3. Select the **Devices manager** tab.
4. Click the **Register** button next to any device that is not already registered. Follow the instructions that display.



Note: On select devices, a QR code can also be used to register the device. If a QR code is present, it will be located on the back of your Wacom device.

Redeem software offers

Once you have created a Wacom ID and registered your device, you can access any software offers that may be available for your Wacom device.


1. [Open Wacom Center](#).
2. In the navigation bar, select **Software offers**.
3. Click the **More Info** button next to an offer to learn more.
4. Click the **View details** link and follow the prompts.

[Do not share my information] [Cookies](#) | [Terms of use](#) | [Privacy Policy](#) | [California Privacy](#)

Keep everything up to date

Wacom occasionally releases Wacom driver and device firmware updates for your Wacom supported device(s).

Updating your device

1. [Open Wacom Center](#).
2. Click the Global settings  icon to proceed to the General settings tab.
3. In the Software updates section, click the **Install update** button next to the Wacom driver or device firmware update.
4. An installation wizard will guide you through the update process.

| [Do not share my information](#) | [Cookies](#) | [Terms of use](#) | [Privacy Policy](#) | [California Privacy](#)

Solve common problems and get help


In Wacom Center you can check driver functions, view diagnostic data, enable driver logging to assist Wacom Support with troubleshooting, and access the Wacom Support site.

Topics on this page

- [Check the driver](#)
- [Run diagnostics for your device](#)
- [Turn on driver logging](#)
- [Access Wacom Support](#)

Check the driver

Checking the driver checks the driver functions and conducts simple troubleshooting, allowing you to restart the driver, reset your device to its default settings, or contact Wacom Support.

1. [Open Wacom Center](#)
2. Click the Global settings  icon in the [navigation bar](#).
3. Scroll down to **Troubleshooting options** and click **Driver check**.
4. After the driver check is complete, you can restart the driver, reset the driver settings, contact [Wacom Support](#), or click **Done**.


Run diagnostics

Running diagnostics provides an overview of the status of your driver, device, touch (if applicable), and pen.

1. [Open Wacom Center](#)
2. Select your device in the [Devices sidebar](#).
3. In the [main content area](#), click **Advanced**.
4. Click the **Diagnostics** button.
5. Refer to the topics under **Wacom Support** in this User Help's Table of Contents for more detailed information on how to diagnose common problems using the Diagnostic data.


Turn on driver logging

Driver logging is turned off by default. Enabling driver logging can assist Wacom Support when diagnosing issues. This creates anonymous driver log files. To turn on driver logging:

1. [Open Wacom Center](#)
2. Click the Global settings  icon.
3. In the **Troubleshooting** section, switch the Driver logging button to "On".
4. You can optionally select **Package log files** if you need the files compressed to send to Wacom.
5. After you have the information Wacom Support requires for debugging, switch the **Driver logging** button back to "Off".

Access Wacom Support

Access Wacom Support to view FAQs, online tutorials, and contact Wacom Support.

1. [Open Wacom Center](#)
2. Click the Help  icon.
3. Click **Support**.
4. You will proceed to the [Wacom Support](#) page in your browser.

[Do not share my information] [Cookies](#) | [Terms of use](#) | [Privacy Policy](#) | [California Privacy](#)

Open Wacom Tablet Properties

For devices supported by Wacom Tablet Properties, you can use the application to customize your device and tool settings (pen, ExpressKeys, etc.).

How you open Wacom Tablet Properties depends on your computer operating system:

- **Windows:** From your application list, select **Wacom Tablet > Wacom Tablet Properties**.
- **macOS:** From **System Preferences**, click on the **Wacom Tablet** icon.




Tip: On Windows 10, Windows 11, and macOS, you can open Wacom Tablet Properties by opening [Wacom Center](#), selecting your device in the [Devices sidebar](#), then selecting a settings link (Pen settings, ExpressKey settings, etc.).

| [Do not share my information](#) | [Cookies](#) | [Terms of use](#) | [Privacy Policy](#) | [California Privacy](#)

On-screen shortcuts

Grid panels (1) and **Radial menus** (2) are On-screen shortcuts that display on your Wacom pen display or – for pen tablets – on your computer's display. You can assign frequently used [actions](#) to the Grid panel or Radial menu keys, then use your pen, mouse, or touch (if supported) to select a key and activate its assigned action.

Pen gestures (3) allow you to pan, scroll, zoom, etc. by pressing and holding a pen button or ExpressKey and moving the pen vertically or horizontally across your device.



The above screenshots are for illustrative purposes only.

Setup and use Grid panels and Radial menus

1. [Create your On-screen shortcut.](#)
2. [Customize the Grid panel or Radial menu keys.](#)
3. [Assign the Grid panel or Radial menu](#) to a customizable component (a pen button, for example).
4. Launch the Grid panel or Radial menu by pressing the customizable component you assigned in the previous step.
5. Click a Grid panel or Radial menu key to activate its assigned action.

Use Pen gestures



Note: Pen gestures are only available on select devices.

1. [Assign a Pen gesture](#) to a pen button or an ExpressKey.
2. Hold down the pen button or ExpressKey while moving the pen tip vertically or horizontally on your device to activate the Pen gesture action (pan, scroll, zoom, etc.).

| Do not share my information | [Cookies](#) | [Terms of use](#) | [Privacy Policy](#) | [California Privacy](#)

Create On-screen shortcuts


The following instructions describe how to create a Grid panel or Radial menu.



Note: Pre-configured Pen gestures come installed in Wacom Center on select devices and do not need to be created.

Create a Grid panel or Radial menu

1. [Open Wacom Center](#).
2. Select **On-screen shortcuts** in the [navigation bar](#).
3. In the On-screen shortcuts sidebar, click the **New** button.
4. Select **New Radial menu** or **New Grid panel**.
5. Select a **Layout** and enter a **Name**.
6. Click the **Apply** button to create your new Radial menu or Grid panel. You will proceed to the On-screen shortcut definition page, where you can [Customize your On-screen shortcuts](#).



| [Do not share my information](#) | [Cookies](#) | [Terms of use](#) | [Privacy Policy](#) | [California Privacy](#)






Customize On-screen shortcuts

The following instructions describe how to customize a Grid panel or Radial menu.



Note: Pre-configured Pen gestures come installed in Wacom Center on select devices and do not require customization.


1. Open [Wacom Center](#).
2. In the [navigation bar](#), click **On-screen shortcuts**.
3. In the On-screen shortcuts sidebar, select the name of the **Grid panel** or **Radial menu** you wish to customize.
4. Click on the Grid panel or Radial menu key and select the action that you wish to assign from the [Action sidebar](#). Repeat for each key.
5. If you select **Keyboard shortcut**:
 - Add a **Key combination** (Ctrl+Z, for example) or **Add special keys** (pre-configured key combinations such as Alt+Tab).
 - Enter a **Name** for the keyboard shortcut.
 - Optionally select an **Icon**.
 - Click **Apply**.
6. The following settings are optional:

Repeat	Select this box if you want the action to repeat when you click and hold the Radial menu or Grid panel key.
Grid or Radial menu size	Move the slider to change the size of the On-screen shortcut when it appears on your screen.
Text size	Move the slider to change the size of the text that displays on the On-screen shortcut when it appears on your screen; the options are small, medium, and large.
Label	Use the drop-down menu to select a label type: Text only , Text & Icon , or Icon only . The selection will display on all the On-screen shortcut keys. Examples: Text only:  Text & Icon:  Icon only: 
Display at Cursor	Leave the box unchecked if you want the On-screen shortcut to appear in the last location you opened it. Select the box if you want the On-screen shortcut to appear next to your cursor when you open it.
Color	Select a color for the entire Grid panel or Radial menu.  Tip: Hover over a key to open a pop-up menu where you can select a color for that specific key.
Apply to all keys	This button is only visible when there is at least one key that uses a different color scheme from a Grid panel or Radial menu. Click this button if you want all of the On-screen shortcut keys to be the same color.
Launch	Select the Launch  icon to view your current On-screen shortcut customizations on your pen display or computer screen.

7. Assign your [On-screen shortcut](#) to a customizable component, such as a pen button or ExpressKey.



Important: Assigning a Grid panel, Radial menu, or Pen gesture to a customizable component (pen button, ExpressKey, etc.) is required in order to open and use the On-screen shortcut.



Click to assign a new action.
The above screenshot is for descriptive purposes; it may not match your screen.

[Do not share my information] [Cookies](#) | [Terms of use](#) | [Privacy Policy](#) | [California Privacy](#)

Assign On-screen shortcuts

The steps below provide instructions on how to assign a Radial menu, Grid panel, or Pen gesture to a pen button. See notes under each set of instructions for other customizable components (ExpressKeys, etc.) to which you can assign On-screen shortcuts.



Important: Assigning a Grid panel, Radial menu, or Pen gesture to a customizable component (pen button, ExpressKey, etc.) is required for the On-screen shortcut to work as expected.

Topics on this page

- [Assign a Radial menu or Grid panel to a pen button](#)
- [Assign a Pen gesture to a pen button](#)


Assign a Radial menu or Grid panel to a pen button



Note: The following steps provide an example. Radial menus and Grid panels can also be assigned to ExpressKeys or touch gestures, depending on your device's available features.

1. [Open Wacom Center](#)
2. Select your device in the [Devices sidebar](#).
3. Follow the instructions labeled A or B, depending on what displays in Wacom Center:
 - A. If the **name of your pen** displays in the Devices sidebar:
 - i. Select the pen name.
 - ii. Click the currently assigned action next to any pen button.
 - iii. In the [Action sidebar](#), open the **Radial menu** or **Grid panel** category, then select the name of the Radial menu or Grid panel you wish to assign.
 - B. If "**Pen settings**" displays in the [main content area](#):
 - i. Click **Pen settings**. You will proceed to **Wacom Tablet Properties**.
 - ii. Click the drop-down arrow next to any pen button.
 - iii. Select **On-screen shortcuts**, then select the name of the Radial menu or Grid panel you wish to assign.
4. Press the pen button you assigned the Radial menu or Grid panel to in the previous step. Your On-screen shortcut will display on the Wacom pen display's screen, or on your computer screen, if using a pen tablet.
5. Select a key to activate its assigned action.



Tip: After launching a Grid panel or Radial menu, select the push pin  icon to keep the Radial menu or Grid panel open at all times.

Assign a Pen gesture to a pen button



Note: The following steps provide an example. Pen gestures can also be assigned to ExpressKeys, depending on your device's available features.

1. [Open Wacom Center](#)
2. Select the device you use your pen with in the [Devices sidebar](#), then select your pen.
3. Click the currently assigned action next to a pen button.
4. In the Actions sidebar, open the **Pen gestures** category, then select the gesture name you wish to assign to the pen button (Pan/Scroll, Zoom, etc.).
5. To use the Pen gesture, press the pen button while moving your pen tip vertically or horizontally on your device to perform the assigned gesture.

[Do not share my information] [Cookies](#) | [Terms of use](#) | [Privacy Policy](#) | [California Privacy](#)

Edit On-screen shortcuts

Use these steps to copy, rename, edit, or delete Radial menus or Grid panels.




Note: Pen gestures cannot be copied, renamed, edited, or deleted.


Topics on this page

- [Copy a Radial menu or Grid panel](#)
- [Rename a Radial menu or Grid panel](#)
- [Edit a Radial menu or Grid panel](#)
- [Delete a Radial menu or Grid panel](#)
- [Change a Grid panel layout](#)

Copy a Radial menu or Grid panel

1. [Open Wacom Center](#).
2. Select **On-screen shortcuts** from the [navigation bar](#).
3. In the On-screen shortcuts sidebar, hover over the shortcut name you want to copy and click the more options  icon.
4. Select **Duplicate**. The duplicated Radial menu or Grid panel will display in the sidebar with a new name (Wacom Screen Keys.1, for example).


Rename a Radial menu or Grid panel

1. [Open Wacom Center](#).
2. Select **On-screen shortcuts** from the [navigation bar](#).
3. In the On-screen shortcuts sidebar, hover over the shortcut name you want to rename and click the more options  icon.
4. Select **Rename**.
5. Edit the name in the pop-up window and click **OK**.

Edit a Radial menu or Grid panel

1. [Open Wacom Center](#).
2. Select **On-screen shortcuts** from the [navigation bar](#).
3. In the sidebar, select an existing On-screen shortcut.
4. In the main content area, make your edits. The changes are saved immediately.

Delete a Radial menu or Grid panel

1. [Open Wacom Center](#).
2. Select **On-screen shortcuts** from the [navigation bar](#).
3. In the On-screen shortcut sidebar, hover over the shortcut name you want to delete and click the more options  icon.
4. Select **Delete**.

Change a Grid panel layout

Layout changes are only available for switching one Grid panel layout to another Grid panel layout (for example: switching from Keypad to Double column 4x2).

1. [Open Wacom Center](#).
2. Select **On-screen shortcuts** from the [navigation bar](#).
3. In the On-screen shortcuts sidebar, select the Grid panel you want to change.
4. In the [main content area](#), select a new layout for the Grid panel.



Tip: If you switch from a larger to a smaller Grid panel (28 to 8 keys, for example), the first eight settings will transfer to the smaller Grid panel. If you switch back, all your original settings will still be present.

[Do not share my information](#) | [Cookies](#) | [Terms of use](#) | [Privacy Policy](#) | [California Privacy](#)

On-screen shortcut layouts

Sample layouts for Grid panels, a Radial menu, and Pen gestures are pictured below.



Note: All On-screen shortcut layouts are in "Text only" format.

Topics on this page

- [Grid panel layouts](#)
- [Radial menu layout](#)
- [Pen gesture layouts](#)


Grid panel layouts

Three Grid panel examples are pictured below.




Note: You can [change the layout of a Grid panel](#) to another Grid panel layout.

Double column (4x2) Grid panel:



Single row (1x8) Grid panel:




Keypad (7x4) Grid panel (similar to the keyboard keypad that displays on your computer monitor):



Radial menu layout

The 8-key Radial menu is pictured below.




Pen gesture layouts

Two Pen gesture examples are pictured below.




Note: Pre-configured Pen gestures come installed in Wacom Center on select devices.

Pan/Scroll Pen gesture:



Zoom Pen gesture:



[Do not share my information](#) | [Cookies](#) | [Terms of use](#) | [Privacy Policy](#) | [California Privacy](#)

Application-specific settings

Settings assigned to customizable components (ExpressKeys, pen buttons, etc.) can be further customized for a specific application. This makes performing functions in the application faster and easier.



Tip: Customizable components that you can create application-specific settings for include ExpressKeys, pen buttons, the pen tip, Touch rings, Rocker rings, On-screen shortcuts, Touch & gestures, and Touch strips, depending on your device.

The Application list at the bottom of Wacom Center's [main content area](#) allows you to add individual applications, and then tailor your customizable component settings for that application. For example, if you select an application icon and change the pen's settings, the changes will apply to the pen only while you are using that application.

Application-specific settings can be used with all Wacom devices, and with the ExpressKey Remote device.





Note: When Application-specific settings are added, the **All** icon changes to **All other applications** and an application icon is displayed for the newly added application(s).

Topics on this page

- [Create an Application-specific setting](#)
- [Remove an Application-specific setting](#)
- [Remove all Application-specific settings from a pen](#)

Create an Application-specific setting

1. [Open Wacom Center](#).
2. Select your device in the [Devices sidebar](#).
3. Select a customizable component (a pen button, for example) for which you wish to create Application-specific settings.
4. At the bottom of the [main content area](#), click the add application  button.
5. In the **Select an application** window, select an application and click **OK**. If you don't see your application, click the **Browse** button to select the executable file of any application installed on your computer.
6. With the newly added application icon selected in the application list, create your Application-specific settings for the customizable component selected in step 3.




The above screenshot is for descriptive purposes; it may not match your screen.




Note: After adding an application, its icon will display in the Application list whenever the customizable component is selected in the [Devices sidebar](#).

Remove an Application-specific setting

1. [Open Wacom Center](#).
2. In the [Devices sidebar](#), select the device and then the tool from which you wish to remove the application-specific setting.
3. Select the application you want to remove from the list of applications at the bottom of the [main content area](#).
4. Click the remove application  button.
5. Click **Delete** to confirm your selection. The selected application is removed from the list, along with any custom tool settings.

Remove all Application-specific settings from a pen

1. [Open Wacom Center](#).
2. In the [navigation bar](#), click the Global settings  icon.
3. Select the **Devices manager** tab, then click **Edit** next to the pen for which you wish to remove Application-specific settings.
4. On the **Edit your pen** screen, click the **Forget pen** button.
5. Place the pen back on your Wacom device. The pen will be added back to the [Devices sidebar](#) with its factory default settings.



Note: If two programs have the same executable file name, they will share the same customized settings.

Touch & gestures

The Touch & gestures feature allows you use only your fingertips on the surface of your Wacom device.

You can use touch as you would on any other Windows or macOS device. Touch is activated whenever you touch the device.

When using touch, you can usually position your fingers as far apart as is comfortable. However, placing your fingers too closely together may be interpreted by the device as input from a single finger, or the device may confuse which finger performed an action. Keep your fingers within the active area.



Tip: Take care to prevent accidental touches on the device when making gestures. For example, if the palm of your hand touches the active area of the device while scrolling or zooming, you may trigger an unanticipated right-click.



Tip: On some device models that support both pen input and touch, the pen disengages touch whenever the pen tip or eraser is within proximity range of the device. Lift the pen and your hand away from the device's active area to enable touch.

| [Do not share my information](#) | [Cookies](#) | [Terms of use](#) | [Privacy Policy](#) | [California Privacy](#)

Touch setup

Touch setup allows you to set up the basic touch input settings for your Wacom pen display. You can set touch input to be fully enabled, disabled except when using On-screen shortcuts, or fully disabled. How you turn touch on and off depends on whether you have a physical touch on/off switch on your device.



Tip: Selective touch allows touch input only on currently displayed [On-screen shortcuts](#), to help avoid unintended touch input from a hand resting on the device, for example.

1. [Open Wacom Center](#)
2. Select your device in the [Devices sidebar](#), then select **Touch & gestures**.
3. Select the **Touch setup** tab.
4. How you turn touch on or off on the Touch setup tab depends on whether your Wacom device has a **physical touch on/off switch**.

Touch status	Does your Wacom device have a physical touch on/off switch?	
	Yes	No
To turn touch on :	Turn the device's touch switch to On.	Select the Enabled button.
To turn touch off :	Turn the device's touch switch to Off.	Select the Disabled button.
Turn touch on for On-screen shortcuts only:	Turn the device's touch switch to Off and choose Selective .	Select the Selective button.

5. For information on customizing touch gestures, see [Basic gestures](#) and [Advanced gestures](#).



Tip: If your device **does not** have a physical touch on/off switch, make turning touch on/off easier by assigning "Touch on/off" to an ExpressKey, pen button, tablet button, etc.

| Do not share my information | [Cookies](#) | [Terms of use](#) | [Privacy Policy](#) | [California Privacy](#)

Basic gestures

Basic gestures are 1-finger and 2-finger touch gestures that can be individually enabled or disabled. Use Basic gestures to navigate, perform mouse clicks, scroll, zoom, or rotate.



Important: Basic gestures are **not supported on Windows** when using a **pen display** product. For pen displays with touch on Windows, see [Advanced gestures](#).

Customize Basic gestures

1. [Open Wacom Center](#).
2. Select your device in the [Devices sidebar](#), then select **Touch & gestures**. You will proceed to the Basic gestures tab.



Note: Basic gestures are supported on **both** pen displays and pen tablets for **macOS**. Basic gestures are only supported on **pen tablets** for **Windows**.



Tip: Hover over a gesture to view an illustration of that gesture.

3. Select or deselect a check box next to a gesture name to activate or deactivate that touch gesture.
4. To modify the **Scroll** gesture, select "Natural" or "Standard" from the drop-down menu to determine the direction of movement when you are scrolling.
5. You can optionally update your device's [Advanced gestures](#).

| [Do not share my information](#) | [Cookies](#) | [Terms of use](#) | [Privacy Policy](#) | [California Privacy](#)

Advanced gestures

Advanced touch gestures include 3-, 4-, and 5-finger gestures. Select a gesture to activate it, or modify the gesture by selecting a new action from the gesture's drop-down menu.

Create custom touch gestures

1. [Open Wacom Center](#).
2. Select your device in the [Devices sidebar](#), then select **Touch & gestures**.
3. Select the **Advanced gestures** tab.



Tip: Hover over a gesture to view an illustration of that gesture.

4. To activate or deactivate a touch gesture, select or deselect the check box next to the gesture name.
5. To modify a touch gesture, click inside the text box and make a selection from the [Action sidebar](#).

Advanced gestures recognition

You can choose Wacom or Windows as your gesture recognizer. This is a global option and will apply to all of your applications, unless you create [Application-specific settings](#).



Note: Whichever gestures recognition setting you select below, Windows always controls 1- and 2-finger gestures on pen displays.

Wacom: This is the default selection. It will provide a consistent touch experience across applications: a 3-finger touch gesture will work the same in both Application A and Application B. This selection allows you to create custom 3-, 4- and 5-finger touch gestures.

Windows: Select this option if you want the Windows operating system to control your 3-, 4- and 5-finger touch gestures. Windows will pass the gesture to each application. If the application supports that gesture, it will be activated. Using the Windows gesture recognizer means that different applications can have different ways of responding to the same gesture. For example: a 3-finger gesture in Application A might perform one behavior, while the same 3-finger gesture in Application B might perform another.



Note: If you choose **Windows**, the Advanced gestures tab will be disabled.

| [Do not share my information](#) | [Cookies](#) | [Terms of use](#) | [Privacy Policy](#) | [California Privacy](#)

Built-in display settings

You can use the Cintiq Pro's built-in display settings controls to adjust a variety of display settings.

Important: Your Cintiq Pro supports standard color spaces that are predefined and calibrated at the factory for each individual display. Wacom recommends customers select a color space appropriate for their environment and type of work. Further customizing of the display colors is an advanced feature.

Tip: If you make changes to the display appearance and cannot return to the original display settings, go to **Display Settings > Reset**.


Tip: To reset **all** built-in display settings, go to **Other Settings > Factory Reset**.

Customize the built-in display settings

1. Press the middle button on the back of your Cintiq Pro to open the built-in display settings menu.



2. Use the ExpressKeys to navigate the built-in display settings menus and select options:



Number	ExpressKey action
1	Select
2	Go back one level
3	Move up/right
4	Move down/left

3. Make your changes. The display settings main menu options are listed below.
 - **Input Source:** Set a specific input port.
 - **Display Settings:** Adjust display attributes such as brightness, color mode, contrast, gamma, and color space.
 - **Display status:** Lists the display resolution and how your pen display is connected via the Input Source.
4. Press the middle button on the back of your Cintiq Pro again to close the built-in display settings menu.

Note: The built-in display settings menu will automatically close after a few moments of inactivity.

Using the Wacom Color Manager

The Wacom Color Manager is an optional tool to help you calibrate your pen display if color management is an important factor in your work flow. Color calibration means that your work will remain true to color across a variety of displays.

This tool combines the Wacom Calibrator hardware and Wacom Profiler software to take the complexity out of color management and make sure that colors on your displays and in your finished work are reproduced exactly as you intended.


For more information about the Wacom Color Manager, visit the [Wacom Support](#) page.

To purchase the Wacom Color Manager, or other parts and accessories, visit the [Wacom eStore](#).

| Do not share my information | [Cookies](#) | [Terms of use](#) | [Privacy Policy](#) | [California Privacy](#)

Wacom Support

If you encounter an issue with your pen or Wacom device, perform the recommended action in any error message that appears on your screen. If that does not resolve the issue, try the following:

1. [Open Wacom Center](#).
2. In the [navigation bar](#), click the Global settings  icon.
3. Under **Troubleshooting Options**, click **Driver check** to evaluate driver function and run simple troubleshooting, if necessary.
4. Review the Quick Start Guide included with your product to make sure the device is set up correctly and that all plugs and connectors are firmly in place.
5. Check the User Help for information regarding the issue.
6. Visit [Wacom Support](#) and search for a topic using the search bar, or select any of the topic category cards to access Frequently Asked Questions.
7. Visit Wacom's [Product Resources](#) page to see if a new driver is available and install it.
8. Run diagnostic tests on your device and tools.



Tip: The diagnostic test instructions ("Test the Wacom device", "Test the Pen", etc.) can be found under **Wacom Support** in this User Help's Table of Contents.

If you tried these suggestions and still have an issue, contact [Wacom Support](#). Please be near your computer with the following information available:

- The make and model of your computer and the version of your operating system.
- Which devices were connected to your computer when the issue occurred.
- The name and version of the software application that you were using when the issue occurred.
- What happened and what you were doing when the issue occurred.
- The exact wording of any error messages that appeared on your screen.
- How you tried to solve the problem.

| Do not share my information | [Cookies](#) | [Terms of use](#) | [Privacy Policy](#) | [California Privacy](#)

Test the creative pen display

After you have connected your pen display to your computer and installed the driver, if nothing appears on the pen display or the pen does not move the cursor, check the connections and tools listed in the steps below.

1. Turn on your computer and wait until it is ready to use.
2. Verify that any power, data, and video cables are properly connected, and that their LED status lights are on.
3. If your pen display is connected to your computer, check the USB connection.
 - Make sure the USB cable is securely connected to an active USB port on your computer.
 - Check the pen display USB cable for damage.
 - If a status LED does not illuminate after your computer is on and has finished booting up, your USB port may be disabled. Verify that you have connected the pen display to an active USB port.
 - Connect the pen display to a different USB port, or to a USB port on another computer, and see if the problem persists.
4. Test touch, if your pen display supports touch. Attempt to move the screen cursor by tracking your finger across the surface. Then tap to select an item.
 - If the driver does not load properly, basic touch movement will be recognized, but other actions and gestures will not. If gestures are not recognized, re-install the driver.
5. Check the ExpressKeys.
6. Check any other tool(s) you may be using.
7. If any of these tests fail, please contact [Wacom Support](#).
8. After testing, you can [customize your device](#) to reconfigure your pen display and tools for any settings you may have been using.

[Do not share my information] [Cookies](#) | [Terms of use](#) | [Privacy Policy](#) | [California Privacy](#)

Test the pen

If your pen does not work as expected, check the assigned settings or reset them to their defaults. Also try the steps outlined on the [Wacom Support](#) page. If you are still having issues, use the diagnostic steps below.



Note: The available features on your pen may vary depending on your device.

1. [Open Wacom Center](#).
2. If you have more than one device connected to your system, select the device you are using the pen with from the [Devices sidebar](#).
3. In the [main content area](#), click **Advanced**.
4. Click the **Diagnostics** button.
5. Hold your pen within 10 mm (0.4 inch) of the surface of the device while watching the **Pointing Device Info**. You should see a value appear after **Proximity**, **Device Name**, **Device Type**, and **Device S/N** (serial number).
6. Move the pen along the surface of the device. As you move the pen, the **X Data** and **Y Data** values should change.
7. Press on the surface with the pen tip and then with the eraser. As you are pressing, the **Switches** and **Pressure** values should change from approximately 0% to approximately 100% when you are pressing with full pressure.
8. Press the tip, eraser, and each pen button, one at a time. When you are pressing each pen button, hold the pen tip slightly above the device surface. As you press each item, the **Switches** number should change to match these numbers:


Pro Pen 3

- Pen button = 4
- Pen button = 3
- Pen button = 2
- Pen tip = 1



Pro Pen 2

- Pen eraser = 1
- Pen button = 3
- Pen button = 2
- Pen tip = 1



9. Move the pen from a vertical position toward the right and then toward the left. The **X Tilt** value should change to approximately +60 when you move to the right. The **X Tilt** value should change to approximately -60 when you move to the left.
10. Move the pen from a vertical position toward the bottom of the device and then toward the top of the device. The **Y Tilt** value should change to approximately +60 when you move toward the bottom. The **Y Tilt** value should change to approximately -60 when you move toward the top.
11. If you are testing an Art Pen, place the pen tip on the surface of the device and slowly rotate the pen on its axis. The **Rotation** value should change as you rotate the pen.
12. If you are testing an Airbrush, move the fingerwheel forward and backward. The **Wheel** value should decrease to approximately 0 when the fingerwheel is all the way forward. The **Wheel** value should increase to approximately 1000 when the fingerwheel is all the way backward.

[Do not share my information] | [Cookies](#) | [Terms of use](#) | [Privacy Policy](#) | [California Privacy](#)

Test the ExpressKeys

If your ExpressKeys do not work as expected, check the assigned actions or reset them to their defaults. Also try the steps outlined on the [Wacom Support](#) page. If you are still having issues, use the diagnostic steps below.

1. [Open Wacom Center](#).
2. Select your device in the [Devices sidebar](#).
3. In the [main content area](#), click **Advanced**.
4. Click the **Diagnostics** button.



Note: The Diagnostics dialog shows dynamic information about the Wacom device, your tool(s), and information for touch-sensitive devices.

5. In the Diagnostics dialog, observe the **Device Info:** column as you test each ExpressKey.
6. Test the keys by pressing them one at a time. Each time you press a key, its number is shown next to the **Left Buttons** or **Right Buttons** category.
7. If the test fails, contact [Wacom Support](#).
8. Click **OK** to close the window.

| Do not share my information | [Cookies](#) | [Terms of use](#) | [Privacy Policy](#) | [California Privacy](#)

Test touch




Important: If basic touch functions work, such as the cursor tracking your finger, but other touch functions do not, reinstall the Wacom driver.

- Move your finger across the surface of the device. The cursor should move with your finger.
- Tap on an item or tap twice on a folder or program. The item should be selected or the folder or program should open.

If the tests fail, please contact [Wacom Support](#) for help.

| [Do not share my information](#) | [Cookies](#) | [Terms of use](#) | [Privacy Policy](#) | [California Privacy](#)

Glossary

Actions	Include mouse clicks, keyboard shortcuts (Ctrl+Z, etc.), navigation (scroll up or down, etc.), opening On-screen shortcuts (Grid panel, etc.), and more. You can assign Actions to customizable components , such as ExpressKeys, pen buttons, etc. When you engage the customizable component, the Action is performed. For example: pressing a pen button to right-click or pressing an ExpressKey to "undo".
Application-specific settings	Device and tool settings that have been customized for individual applications. Application-specific settings are in effect whenever you use the application.
Aspect ratio	The ratio between the vertical and horizontal dimension of the device.
Bluetooth	A method of wireless communication between devices.
Click force	The amount of force you must apply to the pen tip for a click to occur.
Customizable component	Includes ExpressKeys, pen buttons, Touch rings, Rocker rings, Dials, Touch gestures, and Touch strips. The customizable components available to you will vary, depending on your device. You can set a customizable component of your device to perform a specific Action .
Dial	A Dial is customizable control ring on your device. Use your finger to spin the Dial clockwise or counterclockwise to activate time-saving actions such as zoom in/out, scroll up/down, and more. Each Dial has three customizable Modes . Switch between Modes using Dial toggle .
Dial toggle	Pressing the ExpressKey assigned to Dial toggle allows you to switch between the Dial Modes . By default, Dial toggle is assigned to the center ExpressKey  , but you can assign any ExpressKey to Dial toggle.
Digital Ink	Typically, handwritten content which has been created using a pen on a computer in the form of sketches, ink mark-up, or handwriting. The handwriting can be converted to typewritten text or used in its original format.
Displays	An all-encompassing term that can describe a computer monitor, a laptop screen, a Wacom pen display screen, etc.
Display toggle	A feature that allows you to work with your device on all displays, or on one display at a time. Available only on multiple monitor configurations.
Double-click speed	The maximum time that can pass between clicks and still be accepted as a double-click.
Double-tap distance	The maximum distance (in screen pixels) that the screen cursor can move between clicks and still be accepted as a double-click. Increasing the double-click distance makes double-clicking easier, but may cause a delay in brush strokes in some graphics applications.
Eraser-aware application	A software application that has built-in support for the pen eraser. These applications take advantage of the eraser in different ways, depending on what makes sense for the application.
Expand	A motion used when navigating with touch. Touch the device surface with two fingers spaced closely together, then move your fingers apart.
ExpressKeys	The customizable component buttons located on your device.
Grid panel	A rectangular On-screen shortcut.
Mode	A Dial has three Modes. You can assign actions to each Mode. Switch between Modes using Dial toggle .
Modifier	Modifier keys include Shift, Alt, and Ctrl for Windows, or Shift, Control, Command, and Option for macOS. You can customize your tool buttons or ExpressKeys to simulate a modifier key.
Nib	The replaceable pen tip.
On-screen shortcuts	Menus that display on your pen display or on your computer's monitor. You can use On-screen shortcuts to access the settings you frequently use.
Pairing	A method of creating a virtual cable (Bluetooth) link between two devices.
Palm rejection	If a Wacom device supports both pen and touch input, palm rejection allows you to rest your hand on the Wacom device while using your pen without creating unwanted marks.
Pan	A motion used when navigating with touch. Touch the device surface with your fingers and move them in the same direction.
Parallax	The offset between the tip of the pen and the cursor that might display when you are drawing on a Wacom pen display.
Pen display	A Wacom device with a screen. When you draw on a Pen display, you can see what you are drawing on the Pen display's screen.

Pen gestures	Allow you to customize left, right, up, or down pen movements to perform particular actions (undo, redo, scroll, zoom, etc.) while moving your pen tip and pressing a pen button or ExpressKey. Only available on select devices.
Pen holder	A pen storage tool typically attached to your device. Often includes a loop in which you can insert your pen. Is sometimes removable and may contain a nib removal tool and/or extra nibs
Pen input	A method of controlling a computer using the pen.
Pen stand	A stand-alone pen storage tool in which you can place the pen tip-down.
Pen tablet	A Wacom device with an opaque surface. When you draw on your device, you see what you are drawing on your computer's display screen.
Pinch	A motion used when navigating with touch. Touch the display with two fingers spaced slightly apart, then move or 'pinch' your fingers together on the device surface.
Pixel	The smallest unit of measure on your display screen.
Preset settings groups	Preset settings groups allow you to quickly change an entire group of ExpressKey or Dial settings at one time. Preset settings are configured to support specific use cases or can be fully customized.
Pressure sensitive	A quality of the Wacom pen tip and eraser that senses the amount of pressure being applied. This is used to create natural-looking pen, brush, and eraser strokes in applications that are pressure-sensitive.
Pressure-sensitive application	Any application that supports pressure-sensitive input.
Proximity	The height above the device's active area where pen detection occurs.
Radial menu	A circular On-screen shortcut.
Rotate	A motion used when navigating with touch. Touch the device with two fingers spaced slightly apart and rotate them in a circular fashion, move them in opposing directions, or hold one finger stationary and track your other finger around the stationary finger.
Swipe	A motion used when navigating with touch. Touch the device surface with three, four, or five fingers and sweep them quickly across the device in the same direction.
Tap	A motion used when navigating with touch. Touch and lift a single finger (or multiple fingers, depending on the gesture) from the device.
Touch	A method of interacting with a computer using only your fingers on the device. May also be referred to as touch input.
Touch ring	The customizable control ring located on your device.
Touch strips	The customizable control strips located on the back of the Cintiq 22HD.
Touch sensor	The navigation area of your device where touch is detected. The touch sensor resides within the active area, and does not accept pen input.
Track	A motion used when navigating with touch. Touch and move a single finger across the device surface.
USB/Bluetooth selector	A switch that allows you to easily change between host devices connected via a cable or connected wirelessly by Bluetooth.
Viewing angle	The angle at which you are viewing your pen display screen, which can affect where the cursor appears in relation to the pen tip. You can use the Pen to tip alignment feature to account for viewing angle.
Wacom Link/Wacom Link Plus Adapters	Adapters for some creative pen displays on machines without a USB-C port.
Workflow	A Workflow is a related group of actions. An "Editing" workflow might include actions such as Cut, Copy, Paste, and Undo. You can assign Workflows to pen buttons, ExpressKeys, and other customizable components using the Workflow settings feature (available on select devices).

[Do not share my information] [Cookies](#) | [Terms of use](#) | [Privacy Policy](#) | [California Privacy](#)

Order parts and accessories

To purchase parts and accessories for your device, go to the [Wacom Store](#).

You may also contact your local dealer, distributor, or [Wacom Support](#) for your region.



Note: Some parts and accessories may not be available in all regions.

[Do not share my information](#) | [Cookies](#) | [Terms of use](#) | [Privacy Policy](#) | [California Privacy](#)

Care for your device

Follow these care and maintenance tips to ensure optimum performance of your device.



Warning: Do not spill liquids onto your device or pen. The devices may fail if exposed to liquids.

- Clean your device using an anti-static cloth or slightly damp cloth and light pressure.
- Do not wrap the cables around the device when storing it.
- Replace your pen nibs frequently to avoid scratching the surface with worn pen nibs.
- Avoid extremes in temperature.

Make sure to review the **Important Product Information** for additional safety precautions. You can find it in [Wacom Center](#), or on the "Resources for your Wacom device" page: www.wacom.com/download.

| Do not share my information | [Cookies](#) | [Terms of use](#) | [Privacy Policy](#) | [California Privacy](#)

About this document

This online document is referred to as User Help. User Help is intended to assist with the setup, features, and advanced use of Wacom devices, including pens and accessories.

A Quick Start Guide is an additional resource included in the box with your Wacom device and will provide you with an overview of the initial setup or installation process so you can begin using your Wacom device immediately.

Topics on this page

- [Things to know about User Help](#)
- [Device features listed in User Help](#)
- [Access User Help](#)

Things to know about User Help

When viewing User Help, there are several callouts to pay special attention to that give you important information regarding using your Wacom device. The following callouts are present in User Help:



Important: This callout provides specific information that may be necessary for the optimal use of your device or information that you should know about your device.



Warning: This callout provides specific information that may be necessary for the safe use of your device, including but not limited to physical safety or the safe management of your files and data, and best-practice measures to ensure your device works properly.



Note: This callout provides general information about the use of your device, including efficiencies and feature details, variations, or limitations. This callout is also used to identify if a feature or action is not available on all devices.



Tip: This callout provides additional information on how to use your device, including shortcuts and helpful recommendations.



The User Help also contains links to other helpful or relevant information. Clicking on a link will take you to another URL location, most commonly another User Help page, or to the Wacom website.

Device features listed in User Help

User Help provides an in-depth look into the features of Wacom devices. This includes feature definitions, examples, screenshots, and instructions to help users make the most out of their experiences with their devices. However, the **User Help may contain features that are not available on your specific device**. Wacom does its best to annotate the instances where a device feature is mentioned, but is not available on all devices.

Access User Help

You can access User Help from these locations:

- The Wacom Center help  icon.
- The Wacom Tablet Properties help  icon.
- On the [Resources for your Wacom device](#) page: in the search bar, enter your product's name or model number and select the product from the resulting drop-down list. The product's User Help will display in the **Manual & Warranty** section.



Note: User Help is common to Windows and macOS. Screenshots are from a Windows computer, unless otherwise noted.



Note: Information about your specific computer hardware, operating system, and application software is not included. Refer to the product information provided with those products.

[Do not share my information] [Cookies](#) | [Terms of use](#) | [Privacy Policy](#) | [California Privacy](#)

Trademarks

Copyright © 2025 Wacom Co., Ltd.

All rights reserved. Wacom, Intuos, Cintiq, Movink and their respective logos are trademarks and/or registered trademarks of Wacom Co., Ltd.

No part of this information may be reproduced except for your express personal use.

Wacom makes reasonable efforts to provide current and accurate information. However, Wacom reserves the right to change any specifications and product configurations at its discretion, without prior notice and without obligation to include such changes.

Illustrator and Photoshop are either registered trademarks or trademarks of Adobe Systems Incorporated in the United States and/or other countries. Microsoft and Windows are either registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries. Apple, the Apple logo, and Mac are registered trademarks of Apple, Inc., registered in the U.S. and other countries. ExpressKey is a trademark of Ginsan Industries, Inc., and is used with permission. Android is a trademark of Google, Inc.

Many Wacom devices incorporate High Definition Multimedia Interface (HDMI) technology. HDMI, the HDMI logo, and High Definition Multimedia Interface are trademarks or registered trademarks of HDMI Licensing LLC. USB-C is a registered trademark of USB Implementers Forum, Inc.

DisplayPort™ is a trademark owned by the Video Electronics Standards Association (VESA®) in the United States and other countries.

All additional company and product names mentioned in this documentation may be trademarked and/or registered as trademarks. Mention of third-party products is for information purposes only and constitutes neither an endorsement nor a recommendation. Wacom assumes no responsibility with regard to the performance or use of these products.



The hazardous substances of display products sold in mainland China comply with the "Regulations on the Restriction of the Use of Hazardous Substances in Electrical and Electronic Products" and the "Management Catalogue for the Restriction of the Use of Hazardous Substances in Electrical and Electronic Products", and the restrictions on the use of hazardous substances in electrical and electronic products. The Green Labeling System is used in the Implementation of the Conformity Assessment System.

| Do not share my information | [Cookies](#) | [Terms of use](#) | [Privacy Policy](#) | [California Privacy](#)

Privacy


At Wacom, we value your privacy. We use analytics to collect basic information about browsing to improve our User Help. Please see our [Privacy Policy](#) for more information.

Wacom Experience Program for Tablet Driver

You can help Wacom improve its products by participating in the Wacom Experience Program for Tablet Driver. When you participate in the program, the driver will automatically send certain diagnostics and usage data for your Wacom product.



Note: The Wacom Experience Program does not apply to Enterprise devices.

1. [Open Wacom Center](#).
2. Click the Global settings  icon in the [navigation bar](#).
3. Under **Wacom Experience Program for Tablet Driver**, click the **Tablet Driver Privacy Notice** link to learn about the program.
4. To participate in the program, move the **Wacom Experience Program for Tablet Driver** slider to "On".
5. In the pop-up dialog, select the checkbox and click **OK**.

| [Do not share my information](#) | [Cookies](#) | [Terms of use](#) | [Privacy Policy](#) | [California Privacy](#)