

 Contenu  Inhalt  Contenu  Inhoud  Sisältö  
 Inhoud  Contenido  Contenido  Contenido  
 Περιεχόμενα  İçerik



x1



x1



x2




x2

6mm



x1



x1




x2






CR2032

x1




 Getting started  Erste Schritte  Démarrage  Aan de slag  Αποτύπος  
 Operazioni preliminari  Para empezar  Para começar  Kom igång




x1





x1





3x AA/LR6






30mm



x1









CR2032



GB Optional features 05 Optionale Funktionen 06 Options disponibles 07 Opções disponíveis 08 Valinnaiset ominaisuudet 09 Valgrie Funktionen 10 Funzionalità opzionali 11 Opciones disponibles  
 PT Funções opcionais 02 Προαιρετικές λειτουργίες 03 Μόλιγα funkcioner






	Hello	Ding Dong	Westminster	Marimba	Piano	Bell	Telephone	Soft Alert
	•	•					•	•
	•	•	•	•			•	•
	•	•	•	•	•	•	•	•



		3Hrs			6Hrs
		9Hrs			12Hrs

GB Linking 05 Einlernen 06 Programmation 07 Forbinde  
 08 Verknüpfung 09 Linkittäminen 10 Forbinde  
 11 Collegamento 12 Enlace  
 PT Programação 06 Ουδέσση 05 Länkning



GB Trouble shooting 05 Fehlerbehebung 06 Dépannage 07 Probleemoplossing  
 08 Vianmääritys 09 Problemlösning 10 Risoluzione die problemi 11 Solución de  
 problemas 12 Resolução de problemas 13 Αντιμετώπιση προβλημάτων 14 Felsökning

[livewell.honeywell.com](http://livewell.honeywell.com)

