


MEURAL
c a n v a s



Setup Guide

Welcome to the Meural Community

Meural combines the best of art, technology, and design to create products that make us feel something. It's our goal to make art universally accessible, and to help the arts thrive—a mission you're now a part of. To help get you started, here's a brief manual on setting up and using your Meural Canvas.



Vladimir Vukicevic
CEO

Table of Contents

02	Welcome
04	Connecting your Canvas
07	Hanging your Canvas
10	Resources
11	Technical specs

Setting up and controlling your Canvas

To connect your Meural Canvas to Wi-Fi, you'll just need to:

1. Download the Meural app
2. Turn your Canvas on
3. Follow the instructions on your Canvas

Once you're connected to Wi-Fi, you can control your Canvas in three ways: gesture control, the Meural app, and my.meural.

Gesture control

meural.com/videos#gesture

When using your Meural Canvas, you don't touch the frame itself—just like gallery art. Instead, you wave right, left, up, and down across the gesture sensor (about 1" in front of it).



Using the Meural app

meural.com/videos#app

Even after you connect to Wi-Fi, the Meural app will continue to be useful in choosing artwork for your space, changing Canvas settings, and more.






my.meural.com

meural.com/videos#my-meural

“my.meural” is your personal dashboard to browse, curate, and send art to your frame. Our curatorial team adds art every week, so be sure to check in and see what’s new.

You’ll also find it useful in changing your Canvas settings. To do so, simply click on your Canvas in the bottom left.



Canvas settings

Hanging Your Canvas*

For a video walkthrough, visit meural.com/videos#install

To mount the Meural Canvas on your wall, you’ll need:



Tape measure



Pencil



Drill



1/4 inch drill bit



Hammer



Phillips head screwdriver

We provide you with these hanging parts:



Hanging cleat




Screws (with anchors)



Level

*these instructions are intended for drywall

1.



Center and level your cleat.
We recommend a height of 5'
(60") from the floor to the holes
on the cleat.

2.

Mark the holes in pencil
and drill 0.25" pilot holes
2.5" deep for both.




3.



Separate the screws from
the anchors and hammer
the anchors into the holes.


4.



Confirm the orientation of the
cleat and, with the screws, attach
it to your wall.

5.

Plug the power cord's connector
into the back (A) of the frame.



6.

Hang the Meural Canvas by letting the cleats rest in
the metal flaps in the back of the frame.

Note: You can also follow the walkthrough on our
app. Download it at meural.com/app.



Contact us

For questions and feedback, email us at support@meural.com or check out our FAQs at support.meural.com

Our customer support team is available Monday–Friday, 10am–6pm ET, at **1-888-706-3872**

Follow us:



Technical specs

Standard Frame Dimensions - 29.5" x 19.2" x 1.6"

27" IPS Display with Anti-Glare Technology

1920 x 1080 Full HD Resolution

300 cd/m² Brightness

1.8 GHz Quad Core ARM Cortex-A17

2GB DDR3 RAM

8GB Capacity

802.11 a/b/g/n/ac Wi-Fi (supports 2.4GHz and 5GHz)

