


# 3S Quick Start Guide


## Boom Microphone Type



Wired  
Microphone Type

Attachable  
Microphone Type


## Battery Check




## Button Operation




## Power On/Off




## Volume Adjust





## Configuration Menu



## Start/End Intercom




## Bluetooth Pairing Phone, MP3, GPS




Enter 0 0 0 0 PIN


## Headset Pairing Intercom



## Music



## Mobile Phone



**Note:**  
Voice Dial and Redial functions are available only in stand-by mode and not available during music playback.

A full version of the manual is downloadable at [www.sena.com](http://www.sena.com).

**SENA** **Sena Technologies, Inc.**  
[www.sena.com](http://www.sena.com)  
Customer Support: [support.sena.com](mailto:support.sena.com)  
Tel (North America): 408-300-9797  
E-mail: [support@sena.com](mailto:support@sena.com)