

What's in the box?

Here's what you'll find as you unbox your PlayStation®VR. A PlayStation®Camera is required, and may not be included.














HDMI_® cable

USB cable

AC adaptor

AC power cord

VR headset connection cable




VR headset



Stereo headphones (with earpieces)




Processor unit




Printed materials

Make sure your PS4™ system and your TV are turned off.
You can also view a video with simple setup directions (••▶ back cover).





Unplug the HDMI cable from your PS4™ system and then plug it into the processor unit.







Connect your PlayStation®Camera to your PS4™ system.

Hints

- If you already connected your camera, you can skip this step.
- See your camera's instruction manual for setup information.




Plug the HDMI cable (-1) into your PS4™ system and the processor unit.






Plug the USB cable (-②) into your PS4™ system and the processor unit.






Connect the AC power cord to the AC adaptor, and then plug the adaptor cable (-3) into the processor unit. Plug the power cord into an electricity supply.




Slide back the connection cover for the processor unit, and then plug in the VR headset connection cable (-4).



Plug the VR headset (-(5)) into the VR headset connection cable. Plug the supplied stereo headphones into the inline remote for the VR headset.

Hint

Want the best PS VR experience? You'll need to use stereo headphones to enjoy 3D audio. You can also use your own stereo headphones/headset.



Power up your PS VR


- 1. Turn on your TV.
- 2. Press the 🖰 (power) button on your PS4™ system.
- 3. Press the (b) (power) button on the inline remote for the VR headset.

When the VR headset is turned on, the tracking lights (rear) will glow blue.


4. Set up your PS VR.

Follow the on-screen instructions on your TV for setup information and guidance on how to put on your VR headset.

Hint



Remove your VR headset




While pressing the headband release button (A), pull the headband (B) back to remove it.

Hints

- When you don't use your VR headset for an extended period of time, the headset screen goes blank.
- Need some help putting your VR headset back on? Select (Settings) > [Devices] > [PlayStation®VR] on the PS4™ system's function screen for instructions.

Turn off your VR headset



To turn off your VR headset, press the \circlearrowleft (power) button (A) on the inline remote. The tracking lights (B) will go out.

Hint

You can continue to use your PS4[™] system to play games that are not VR enabled. You don't have to reconnect cables or unplug the processor unit.

Instruction manual

Carefully read the PS VR Instruction Manual before you attempt to use this product.

Step-by-step setup guide

Visit http://www.sie.com/psvr/ to view a step-bystep setup video. You can also access the video using the QR code.

"🎝 " and "PlayStation" are registered trademarks or trademarks of Sony Interactive Entertainment Inc.

'SONY" is a registered trademark of Sony Corporation.

The terms HDMI and HDMI High-Definition Multimedia Interface, and the HDMI Logo are trademarks or registered trademarks of HDMI Licensing, LLC in the United States and other countries.

Design and specifications are subject to change without notice.

Functional descriptions in this document may not reflect future updates to your PS4™ system software and PS VR device software. Illustrations may differ from the actual products.





4-588-817-**21**(1)



