






wacom® Cintiq



1



wacom.com/start


wacom.com/manuals

wacom.com/support


2

1

110/240V



2



3

3 wacom.com/start



EN Download the driver at wacom.com/start. Then register your product to access all Wacom services.

Laden Sie den Treiber unter wacom.com/start herunter.

DE Registrieren Sie danach Ihr Produkt, um Zugang zu allen Services von Wacom zu erhalten.

Download het stuurprogramma op wacom.com/start.

NL Registreer je product vervolgens om toegang te krijgen tot alle diensten van Wacom.

Ladda ner drivrutinen på wacom.com/start.

SV Registrera sedan produkten för att komma åt alla tjänster från Wacom.

DA Download driveren på wacom.com/start. Registrer herefter dit produkt for at få adgang til alle Wacom tjenester.

FR Téléchargez le pilote sur wacom.com/start. Inscrivez ensuite votre produit pour accéder à tous les services Wacom.

IT Scarichi il driver su wacom.com/start. Quindi registri il prodotto per accedere a tutti i servizi Wacom.

ES Descargue el controlador en wacom.com/start. A continuación, registre su producto para acceder a todos los servicios de Wacom.

JP wacom.com/start から「Wacom Cintiq」を選び、タブレットドライバをダウンロードしてください。製品登録を行っていただくことで各種サービスが受けられます。

KR wacom.com/start 에서 드라이버를 다운로드하십시오. 그런 다음 제품을 등록하시면 Wacom 서비스 전체에 액세스하실 수 있습니다.

在 wacom.com/start 下載驅動程式。然後註冊產品以獲取全部 Wacom 服務。

PT Baixe o driver em wacom.com/start. Depois registre seu produto, para acessar todos os serviços Wacom.

RU Скачайте драйвер на wacom.com/start. Затем зарегистрируйте свой продукт для получения доступа ко всем сервисам Wacom.

PL Pobierz sterownik ze strony internetowej wacom.com/start. Następnie zarejestruj swój produkt, aby uzyskać dostęp do wszystkich usług Wacom.

CS Stáhněte si ovladač na wacom.com/start. Pak zaregistrujte svůj výrobek, abyste získali přístup ke všem službám Wacom.

BG Изтеглете драйвера от wacom.com/start. След това регистрирайте своя продукт, за да получите достъп до всички услуги на Wacom.


FI Lataa ajuri alas osoitteesta wacom.com/start. Rekisteröi sitten tuotteesi päästäksesi käsiksi kaikkiin Wacom-palveluihin.

TR wacom.com/start adresinden sürücüyü indirin. Daha sonra, tüm Wacom servislerine erişmek için ürününüzü kaydedin.


在 wacom.com/start 下載驅動程式。然後註冊產品以獲取全部 Wacom 服務。

SC wacom.com/start 下載驅動程式。然後註冊產品以獲取全部 Wacom 服務。


6




7





8



9



10



©2019 Wacom Co., Ltd. All rights reserved.
Wacom, Cintiq and their respective logos
are trademarks and/or registered trademarks
of Wacom Co., Ltd.

©2019 Wacom Co., Ltd. Tous droits réservés.
Wacom, Cintiq et leurs logos correspondants
sont des marques commerciales et/ou
déposées de Wacom Co., Ltd.

 wacom.com/manuals

Printed in China | PRN-B216(A)

11



wacom[®]
Cintiq