

1	APPLICATION	3
2	DESCRIPTION (FIG. A)	3
3	PACKAGE CONTENT LIST	3
4	SYMBOLS	3
5	GENERAL POWER TOOL SAFETY WARNINGS	4
5.1	<i>Work area</i>	4
5.2	<i>Electrical safety</i>	4
5.3	<i>Personal safety</i>	4
5.4	<i>Power tool use and care</i>	5
5.5	<i>Service</i>	5
6	ADDITIONAL SAFETY INSTRUCTIONS FOR HAMMER DRILLS 5	5
7	BEFORE USING THE TOOL FOR THE FIRST TIME	6
7.1	<i>Fitting and changing tools (Fig. 1)</i>	6
7.2	<i>Removing SDS-Max tool</i>	6
8	OPERATION	6
8.1	<i>Switching ON/OFF</i>	6
8.2	<i>Variable speed</i>	6
8.3	<i>Handle attachment (Fig. 2)</i>	7
8.3.1	<i>Side handle</i>	7
8.3.2	<i>D-shaped handle</i>	7
8.4	<i>Use</i>	7
8.5	<i>Hammer/drill switch</i>	7
9	CLEANING AND MAINTENANCE	8
9.1	<i>Cleaning</i>	8
10	TECHNICAL DATA	8
11	NOISE	8
12	SERVICE DEPARTMENT	8
13	STORAGE	8
14	WARRANTY	9
15	ENVIRONMENT	9

16 **DECLARATION OF CONFORMITY** **10**

HAMMER DRILL / DEMOLITION HAMMER 1600W POWX1190

1 APPLICATION

Your hammer drill can be universally used for hammer drilling and chiseling in stone and concrete.

It is not designed for commercial use.



WARNING! Read this manual and general safety instructions carefully before using the appliance, for your own safety. Your power tool should only be passed on together with these instructions.

2 DESCRIPTION (FIG. A)

- | | |
|---------------------------|---|
| 1. Drill/chisel holder | 8. Power cable |
| 2. Fastening sleeve | 9. Power switch |
| 3. Fixation knob D-handle | 10. Attachment point for auxiliary handle |
| 4. D-handle | 11. Anti Vibration System |
| 5. Auxiliary handle | 12. Oil cover |
| 6. Mode selector | 13. Speed control dial |
| 7. Rear Handle | |

3 PACKAGE CONTENT LIST

- Remove all packing materials.
- Remove remaining packaging and transit supports (if existing).
- Check the completeness of the packing content.
- Check the appliance, the power cord, the power plug and all accessories for transportation damages.
- Keep the packaging materials as far as possible till the end of the warranty period. Dispose it into your local waste disposal system afterwards.



WARNING Packing materials are no toys! Children must not play with plastic bags! Danger of suffocation!

- | | |
|---------------------------|-----------------------|
| - drill Ø18 x 320mm | -2 x auxiliary handle |
| - SDS point chisel: 320mm | -Wrench |
| - Grease cup | |



When parts are missing or damaged, please contact your dealer.

4 SYMBOLS

In this manual and/or on the machine the following symbols are used:

	Read manual before use		In accordance with essential requirements of the European directive(s)
	Class II - The machine is double insulated; Earthing wire is therefore not necessary.		Always wear safety goggles

5 GENERAL POWER TOOL SAFETY WARNINGS

Read all safety warnings and all instructions. Failure to follow all warnings and instructions may result in electric shock, fire and/or serious injury. Save all warnings and instructions for future reference. The term "power tool" in the warnings refers to your mains operated (corded) power tool or battery operated (cordless) power tool.

5.1 Work area

- Keep work area clean and well lit. Cluttered and dark areas invite accidents.
- Do not operate power tools in explosive atmospheres, such as in the presence of flammable liquids, gases or dust. Power tools create sparks which may ignite the dust or fumes.
- Keep children and bystanders away while operating a power tool. Distractions can cause you to lose control.

5.2 Electrical safety



Always check that the power supply corresponds to the voltage on the rating plate.

- Power tool plugs must match the outlet. Never modify the plug in any way. Do not use any adapter plugs with earthed (grounded) power tools. Unmodified plugs and matching outlets will reduce risk of electric shock.
- Avoid body contact with earthed or grounded surfaces such as pipes, radiators, ranges and refrigerators. There is an increased risk of electric shock if your body is earthed or grounded.
- Do not expose power tools to rain or wet conditions. Water entering a power tool will increase the risk of electric shock.
- Do not abuse the cord. Never use the cord for carrying, pulling or unplugging the power tool. Keep cord away from heat, oil, sharp edges or moving parts. Damaged or entangled cords increase the risk of electric shock.
- When operating a power tool outdoors, use an extension cord suitable for outdoor use. Use of a cord suitable for outdoor use reduces the risk of electric shock.
- If operating a power tool in a damp location is unavoidable, use a residual current device (RCD) protected supply. Use of an RCD reduces the risk of electric shock.

5.3 Personal safety

- Stay alert, watch what you are doing and use common sense when operating a power tool. Do not use a power tool while you are tired or under the influence of drugs, alcohol or medication. A moment of inattention while operating power tools may result in serious personal injury.
- Use safety equipment. Always wear eye protection. Safety equipment such as dust mask, non-skid safety shoes, hard hat, or hearing protection used whenever conditions require will reduce personal injuries.
- Avoid accidental starting. Ensure the switch is in the off position before plugging in. Carrying power tools with your finger on the switch or plugging in power tools that have the switch on invites accidents.
- Remove any adjusting key or wrench before turning the power tool on. A wrench or a key left attached to a rotating part of the power tool may result in personal injury.
- Do not overreach. Keep proper footing and balance at all times. This enables better control of the power tool in unexpected situations.
- Dress properly. Do not wear loose clothing or jewellery. Keep your hair, clothing and gloves away from moving parts. Loose clothes, jewellery or long hair can be caught in moving parts.

- If devices are provided for the connection of dust extraction and collection facilities, ensure these are connected and properly used. Use of these devices can reduce dust related hazards.

5.4 Power tool use and care

- Do not force the power tool. Use the correct power tool for your application. The correct power tool will do the job better and safer at the rate for which it was designed.
- Do not use the power tool if the switch does not turn it on and off. Any power tool that cannot be controlled with the switch is dangerous and must be repaired.
- Disconnect the plug from the power source before making any adjustments, changing accessories, or storing power tools. Such preventive safety measures reduce the risk of starting the power tool accidentally.
- Store idle power tools out of the reach of children and do not allow persons unfamiliar with the power tool or these instructions to operate the power tool. Power tools are dangerous in the hands of untrained users.
- Maintain power tools. Check for misalignment or sticking of moving parts, breakage of parts and any other condition that may affect the power tool's operation. If damaged, have the power tool repaired before use. Many accidents are caused by poorly maintained power tools.
- Keep cutting tools sharp and clean. Properly maintained cutting tools with sharp cutting edges are less likely to stick and are easier to control.
- Use the power tool, accessories and tool bits etc., in accordance with these instructions and in the manner intended for the particular type of power tool, taking into account the working conditions and the work to be performed. Use of the power tool for operations different from intended could lead to a hazardous situation.

5.5 Service

- Have your power tool serviced by a qualified repair person using only identical replacement parts. This will ensure that the safety of the power tool is maintained.

6 ADDITIONAL SAFETY INSTRUCTIONS FOR HAMMER DRILLS

- Check the voltage (volt) marked on the rating plate.
- When using cable drums, run all the cable off the drum. Minimum conductor cross section: 1.0 mm².
- When using the electric hammer drill outdoors, connect to the power supply with a type H07RN-F 3G 1.5 mm² extension cable and rain-water-protected plugs in proper working order.
- Make sure of your footing on ladders and scaffolding when drilling free-handed.
- Use a line detector to localize lines in walls with concealed electric, water or gas lines. Avoid touching live components or conductors.
- Wear ear muffs to protect your hearing. Loss of hearing can be a gradual process!
- Wear goggles and use a dust mask on jobs generating dust.
- Do not use in areas where there are vapours or flammable liquids.
- Always pull the plug out of the socket before cleaning or making changes to the machine.
- Protect the power cable from damage. Oil and acid can damage the cable.
- Never overload the machine.
- Secure all workpieces sufficiently.
- **Important!** It is imperative to follow all national safety regulations concerning installation, operation and maintenance.
- Chisel bits and drill bits may be flung out of the machine accidentally and cause serious injury:
- Before starting to work, always check that the chisel or drill bit is property locked in the chuck.
- Examine the chuck regularly for signs of wear or damage.

- Never start up a hammer tool until it pressed against a workpiece (wall, ceiling, etc.).
- When you are finished, unplug the hammer drill from the electric supply and remove the chisel or drill bit from the machine.
- Always disconnect the hammer drill from the electric supply before you change a chisel or drill bit.
- Protect your eyes and other workers from flying particles and splinters. Wear a helmet! Set up partition walls!
- Wear work gloves to protect fingers from bruising and grazing.
- Vibrations can injure the hand-arm system. Keep exposure to vibrations as short as possible.
- Always lead the mains cable away backwards from the device.
- Store the device where it is inaccessible to children.
- When carrying out work, always hold the device with both hands and ensure that you have a stable standing position.

7 BEFORE USING THE TOOL FOR THE FIRST TIME

- Examine the place where the device is to be used for hidden electrical cables, gas and water pipes using a pipe finding device.
- Before connecting to the mains, ensure care that the mains voltage corresponds to the details on the rating plate.
- Ensure that the power switch is in the OFF position. If the plug is connected to a mains while the power switch is in the ON position, the power tool will start operating immediately, which could cause serious accidents.
- When the work area is removed from the power source, use an extension cord of sufficient thickness and rated capacity. The extension cord should be kept as short as practicable.

7.1 Fitting and changing tools (Fig. 1)

The device is equipped with a SDS-Max attachment system.

- Clean tools and grease with a thin layer of machine grease before fitting.
- Pull back fastening sleeve and hold.
- Push and rotate the dust-free tool into the tool holder as far as it will go. The tool will lock automatically.
- Check that it has locked by pulling the tool

7.2 Removing SDS-Max tool

Pull back fastening sleeve, hold and remove tool.



**Accessories can be hot after use. Don't touch the tip of accessory by hand!
Please always use protective gloves to remove accessory.**

8 OPERATION

8.1 Switching ON/OFF

- Switching on: Press the operating switch (9).
- Switching off: Release the operating switch(9)

8.2 Variable speed

The speed can be adjusted between Min. and Max. speed through rotating the speed control dial (13) from 1 to 6.

It will accelerate when adjust the controller from 1 to 6. If dial 6 to 1, the machine slow down. choose the right speed according to the work piece.

8.3 Handle attachment (Fig. 2)

For reasons of safety, only use the hammer drill with handle attachment.
You will be able to obtain a safe body position when working by rotating the handle attachment.

8.3.1 Side handle

The auxiliary handle can be attached in two different mounting holes: left and right.
remove the auxiliary handle subassembly in the opposite way.

8.3.2 D-shaped handle

- To loosen: turn fixation knob (3) to the left.
- Now the handle can be turned in the desired position.
- Tighten the fixation knob (3) again, by turning to the right.

8.4 Use

- Set de mode selector (6) to hammer mode
- After placing the tip of the tool on concrete surface, switch ON
- By utilizing the weight of the machine and by firmly holding the hammer drill with both hands, you can effectively control the subsequent recoil motion.



After long time of use, the cylinder case becomes hot. Therefore, be careful not to burn your hands.



Don't apply big pressure on the machine. The hammer mechanism is activated by applying a slight pressure on the tool when the chisel bit is in contact with the work-piece.



In some cases, it is necessary to punch up the bit against the crushing position forcibly in order to begin the striking strokes. This is not due to malfunction of the tool, it means that the safe guard mechanism against no-load striking is working.

8.5 Hammer/drill switch

The mode selector (6) can switch the hammer and hammer/drill functions.

	<p>Hammer/ drill mode: Drill in masonry, concrete and natural stone. Don't use the hammer drill function for ceramic tile or others material can not withstand impact energy.</p>
	<p>Hammer mode: Drill in masonry, concrete and natural stone.</p>

9 CLEANING AND MAINTENANCE



Attention ! Before performing any work on the equipment, pull the power plug.

9.1 Cleaning

- Keep the ventilation slots of the machine clean to prevent overheating of the engine.
- Regularly clean the machine housing with a soft cloth, preferably after each use.
- Keep the ventilation slots free from dust and dirt.
- If the dirt does not come off use a soft cloth moistened with soapy water.



Never use solvents such as petrol, alcohol, ammonia water, etc. These solvents may damage the plastic parts.

10 TECHNICAL DATA

POWX1190

Voltage	220-240 V – 50 Hz
nominal power output	1600 W
No load speed	0 -330 min ⁻¹
Rate of percussion (Impacts / min)	0-2300 ipm
Single impact power	25 Joule
Drill capacity concrete	50 mm

11 NOISE

Noise emission values measured according to relevant standard. (K=3)

Acoustic pressure level LpA	96 dB(A)
Acoustic power level LwA	107 dB(A)



ATTENTION! Wear hearing protection when sound pressure is over 85 dB(A).

aw (Vibration)	22,3 m/s ²	K = 1,5 m/s ²
----------------	-----------------------	--------------------------

12 SERVICE DEPARTMENT

- Damaged switches must be replaced by our after-sales service department.
- If the connecting cable (or mains plug) is damaged, it must be replaced by a particular connecting cable which is available from our service department. Replacement of the connecting cable must only be carried out by our service department (see last page) or by a qualified person (qualified electrician).

13 STORAGE

- Thoroughly clean the whole machine and its accessories.
- Store it out of the reach of children, in a stable and secure position, in a cool and dry place, avoid too high and too low temperatures.
- Protect it from exposure to direct sunlight. Keep it in the dark, if possible.
- Don't keep it in plastic bags to avoid humidity build-up.

14 WARRANTY

- This product is warranted for a 36-month period effective from the date of purchase by the first user.
- This warranty covers all material or production flaws excluding : batteries, chargers, defective parts subject to normal wear & tear such as bearings, brushes, cables, and plugs, or accessories such as drills, drill bits, saw blades, etc. ; damage or defects resulting from maltreatment, accidents or alterations; nor the cost of transportation.
- Damage and/or defects resulting from inappropriate use also do not fall under the warranty provisions.
- We also disclaim all liability for any bodily injury resulting from inappropriate use of the tool.
- Repairs may only be carried out by an authorised customer service centre for Powerplus tools.
- You can always obtain more information at the number 00 32 3 292 92 90.
- Any transportation costs shall always be borne by the customer, unless agreed otherwise in writing.
- At the same time, no claim can be made on the warranty if the damage of the device is the result of negligent maintenance or overload.
- Definitely excluded from the warranty is damage resulting from fluid permeation, excessive dust penetration, intentional damage (on purpose or by gross carelessness), inappropriate usage (use for purposes for which the device is not suitable), incompetent usage (e.g. not following the instructions given in the manual), inexpert assembly, lightning strike, erroneous net voltage. This list is not exhaustive.
- Acceptance of claims under warranty can never lead to the prolongation of the warranty period nor commencement of a new warranty period in case of a device replacement.
- Devices or parts which are replaced under the warranty therefore remain the property of Varo NV.
- We reserve the right to reject a claim whenever the purchase cannot be verified or when it is clear that the product has not been properly maintained. (Clean ventilation slots, carbon brushes serviced regularly, etc.).
- Your purchase receipt must be kept as proof of date of purchase.
- Your appliance must be returned undismantled to your dealer in an acceptably clean state, (in its original blow-moulded case if applicable to the unit), accompanied by proof of purchase.

15 ENVIRONMENT

Should your appliance need replacement after extended use, do not discard it with the household rubbish but dispose of it in an environmentally safe way. Waste produced by electrical machine items should not be handled like normal household rubbish. Please recycle where recycle facilities exist. Check with your Local Authority or retailer for recycling advice.

16 DECLARATION OF CONFORMITY



VARO N.V. - Vic. Van Rompuy N.V.- Joseph Van Instraat 9 - BE2500 Lier - BELGIUM,
declares that,

Product : Hammer drill / Demolition hammer 1600W

Trade mark : POWERplus

Model : POWX1190

is in conformity with the essential requirements and other relevant provisions of the applicable European Directives, based on the application of European harmonized standards. Any unauthorized modification of the apparatus voids this declaration.

European Directives (including, if applicable, their amendments up to the date of signature);

2011/65/EU

2006/42/EC

2014/30/EU

European harmonized standards (including, if applicable, their amendments up to the date of signature);

EN60745-1 : 2009

EN60745-2-6 : 2010

EN55014-1 : 2017

EN55014-2 : 2015

EN61000-3-2 : 2014

EN61000-3-3 : 2013

Keeper of the Technical Documentation : Philippe Vankerkhove, VARO – Vic. Van Rompuy N.V.

The undersigned acts on behalf of the company CEO,

Philippe Vankerkhove
Regulatory Affairs – Compliance Manager
Lier, 03/10/2019